

Télécommande Compatible TV
TELEFUNKEN et autres marques

TC-ORIGINAL-6

Bravo



CARACTÉRISTIQUES

- Télécommande Compatible TV TELEFUNKEN HITACHI TOSHIBA SHARP FINLUX HAIER PROLINE et autres marques
- Aucune programmation requise
- Maintient les codes pendant le changement de pile
- Garantie 2 ans

Modèles compatibles

| | | | | | | | |
|------------|--------------------|-----------|------------------|---------------|---------------------|---------------|--------------------|
| Marca | Modèle | AKAI | ALED3205TBK | AUTOVOX | AX42P05S | CONTIN.EDISON | CELED4011866 |
| ACO.SOLUT. | LCD37751F1060P | AKAI | ALED3209TBK | AUTOVOX | AX42P15S | CONTIN.EDISON | CELED4083 |
| AEQ | 1406TX(v2) | AKAI | ALED3209TWE | AUTOVOX | AX42P16 | CONTIN.EDISON | CELED43S04B3 |
| AEQ | COSMO4220 | AKAI | ALED3222BK | AUTOVOX | AX42PB26(v1) | CONTIN.EDISON | CELED49S01136B3 |
| AEQ | CTV4816ST/VTLCD | AKAI | ALED3224BK | AUTOVOX | AX42TFT17HDN | CONTIN.EDISON | CELED558FB6 |
| AEQ | CTV4817ST/VTLCD | AKAI | ATE40K2404K | AUTOVOX | RC1055 | CONTIN.EDISON | CETVLED26HD3 |
| AEQ | CTV4818ST/VTLCD | AKAI | LCV20NE7 | AUTOVOX | RC1243 | CRANKER | CRTV20100 |
| AEQ | CTV4819SR/VT | AKAI | LCV30WHDE12LCD | AUTOVOX | RC1542 | CRANKER | CRTV20200 |
| AEQ | CTV4819ST/VTLCD | AKAI | PDP42VTB | AUTOVOX | RC1543 | CRANKER | CRTV22100 |
| AEQ | CTV4820ST/VTPLASMA | AKAI | TVL241 | AUTOVOX | RC1546 | CRANKER | CRTV24200 |
| AEQ | LCD15 | AKAI | TVL321 | AUTOVOX | RC3900 | CRANKER | CRTV24300 |
| AEQ | LCD2708 | AKAI | TVL391 | AYA | A19AD1901 | CRANKER | CRTV24400 |
| AEQ | LCDCOSMO1508 | ALBA | ALCD15TV5 | AYA | A20HD2001 | CRANKER | CRTV24600S |
| AEQ | LCDCOSMO1510 | ALBA | CTV3484BLKAK36 | AYA | A22BD2201 | CRANKER | CRTV24700 |
| AEQ | LCDCOSMO1701 | ALBA | CTV3484SIL | AYA | A26BC2602 | CRANKER | CRTV24700S |
| AEQ | LCDCOSMO2001 | ALBA | CTV3485XI | AYA | A32BD3202 | CRANKER | CRTV28100 |
| AEQ | LCDCOSMO2010 | ALLSTAR | AS32L | AYA | A32HD3203 | CRANKER | CRTV28200 |
| AEQ | LCDCOSMO2706 | AMSTRAD | 14TV1460 | AYA | A40FHD4001 | CRANKER | CRTV28400 |
| AEQ | LCDCOSMO3007 | AMSTRAD | 42PLASMASILVER | AYA | A49FHD4901 | CRANKER | CRTV32100 |
| AEQ | LCDCOSMO3710(v1) | AMSTRAD | CD3010GO | AYA | A49FHD4902 | CRANKER | CRTV32200 |
| AEQ | LCDCOSMO4205 | AMSTRAD | "PLASMASILVER42" | BASICLINE | 42PTVPLASMA | CRANKER | CRTV32210 |
| AEQ | LCDCOSMO4210 | AMSTRAD | "TFT20"LCD" | BELSON | BSV1584 | CRANKER | CRTV32300 |
| AEQ | LCDCOSMO5005 | AMSTRAD | TV15TFT | BELSON | BSV19183 | CRANKER | CRTV32400 |
| AEQ | LCDTV38-5150 | ANDERSSON | X1 | BELSON | BSV19184 | CRANKER | CRTV32500 |
| AEQ | LCDTV66-5260 | ANDERSSON | XQ3/01 | BELSON | BSV1984V2 | CRANKER | CRTV32600S |
| AEQ | LCDTV68-5270 | ANSONIC | 40SMF1 | BELSON | BSV2653 | CRANKER | CRTV32700S |
| AEQ | PLASMATV106-4205 | ARIELLI | LED2065HD | BELSON | BSV2684 | CRANKER | CRTV39300 |
| AEQ | STRATOS14 | ARIELLI | LED2288FHD | BELSON | BSV2684V2 | CRANKER | CRTV40100 |
| AEQ | STRATOS2005TX | ARIELLI | LED2498HD | BELSON | BSV3256 | CRANKER | CRTV40200 |
| AEQ | STRATOS21 | ARIELLI | LED3229HD | BELSON | BSV3292V1 | CRANKER | CRTV40300 |
| AEQ | STRATOS2125ST/TX | ARIELLI | LED3299HD | BELSON | BSV3295 | CRANKER | CRTV40500S |
| AEQ | STRATOS29 | ARIELLI | LED3207HD | BELSON | BSV3752 | CRANKER | CRTV40700S |
| AEQ | TL30LC08 | ARIELLI | LED3208HD | BLOOM | BL2028T(V2) | CRANKER | CRTV48200 |
| AEQ | TVLCD15(v1) | ARIELLI | LED4018HD | BLUESKY | BK7759HI | CRANKER | CRTV49100 |
| AKAI | AKTV2013T | AUCHAN | 32168 | BLUESKY | BL5126TX | CRANKER | CRTV49200 |
| AKAI | AKTV2014T | AUDIOLA | "TV"LCD" | BLUESKY | BLK5126S | CRANKER | CRTV49700S |
| AKAI | AKTV220(V2) | AUTOVOX | 10032173 | BLUESKY | BS1408TX | CROSSWOOD | V20M |
| AKAI | AKTV2215T | AUTOVOX | AX14Q07 | BLUESKY | BS2006VE | CROWN | 14FLAT |
| AKAI | AKTV2414T | AUTOVOX | AX15DDV68 | BLUESKY | BS3503LNSLV | CROWN | ALCD1507P |
| AKAI | AKTV2415T | AUTOVOX | AX15TFT04S | BLUESKY | BS3605TX | CROWN | CTT3207W |
| AKAI | AKTV290 | AUTOVOX | AX15TFT05S | BLUESKY | BS3606TX | DANTAX | 19LDV400DC |
| AKAI | AKTV321 | AUTOVOX | AX15TFT06S | BLUESKY | BS3703LNSLV | DANTAX | 22LCDV9 |
| AKAI | AKTV3211 | AUTOVOX | AX15TFT17 | BLUESKY | BSLCD30W | DANTAX | 22LDV400DC |
| AKAI | AKTV390T | AUTOVOX | AX19DDV68 | BLUESKY | PDP4210ST | DANTAX | 22LED300 |
| AKAI | AKTV400 | AUTOVOX | AX19LED70 | BOGO | BO0022FHD | DANTAX | 26LCDV9 |
| AKAI | AKTV405T(V2) | AUTOVOX | AX19LED73 | BUSH | DLED24HSDVDW | DANTAX | 26LDV400 |
| AKAI | AKTV408TS | AUTOVOX | AX19UDV70 | BUSH | DLED321273DCNT | DANTAX | 30LCDV1 |
| AKAI | AKTV409TS | AUTOVOX | AX20Q03S | BUSH | DLED32165HD | DANTAX | 32LCDV9 |
| AKAI | AKTV430 | AUTOVOX | AX20Q04S | BUSH | DLED32165HDY | DANTAX | 32LED500PVR |
| AKAI | AL1912TBK | AUTOVOX | AX20Q07 | BUSH | DLED3226SHDCNT | DANTAX | 32LED501PVR |
| AKAI | AL2222BK | AUTOVOX | AX20TFT04S | BUSH | DLED3226SHDOVD8 | DANTAX | 32LV802 |
| AKAI | AL2222WE | AUTOVOX | AX20TFT05S | BUSH | DLED3226SHDOVDW | DANTAX | 42PLASMAV2 |
| AKAI | AL2408TBK | AUTOVOX | AX20TFT06 | BUSH | DLED32287HDCNTDFVP | DANTAX | 42PLASMAV3 |
| AKAI | AL2422BK | AUTOVOX | AX20TFT16(V2) | BUSH | DLED40287FHD | DIGIHOME | D32151HDLED |
| AKAI | AL2605TBK | AUTOVOX | AX20TFT17 | BUSH | DLED40287FHDCNTDFVP | DIGIHOME | DH04L15S |
| AKAI | AL2608TBK | AUTOVOX | AX21Q05S | BUSH | DLED43287FHD | DIGIHOME | DH04LCD20S |
| AKAI | AL2622BK | AUTOVOX | AX21Q06S | BUSH | DLED43287FHDCNTDFVP | DIGIHOME | DH04LCP20S |
| AKAI | AL3208TBK | AUTOVOX | AX21RF05S | BUSH | DLED48287HDCNTDFVP | DIGIHOME | DM04LDC15S |
| AKAI | AL3212SMART | AUTOVOX | AX21RF048 | BUSH | ELED32240HDCNT | DIGILOGIC | D14PTV1 |
| AKAI | AL3214SMART | AUTOVOX | AX22DDV68 | BUSH | LED24127DVDcnt | DIGIQUEST | DGE32NETFLIX |
| AKAI | AL3222BK | AUTOVOX | AX22LCD70 | BUSH | LED24265DVDcntDFVP | DIGIQUEST | DGE39NETFLIX |
| AKAI | AL3222SMART | AUTOVOX | AX22LED70 | BUSH | LED24265DVDcntDFVP | DIGIQUEST | DGE55NETFLIX |
| AKAI | AL3224SMART | AUTOVOX | AX22LED73 | BUSH | LED32127HDCNT | DIGIQUEST | DGQ2012V |
| AKAI | AL3910TBK | AUTOVOX | AX22LED83 | BUSH | LED32982HDT | DIGIQUEST | DGQ2212VPHD |
| AKAI | AL3914SMART | AUTOVOX | AX22UDV70 | BUSH | LED37916FHD | DIGIQUEST | DGQ22169HEVC |
| AKAI | AL4008TBK | AUTOVOX | AX23LED70 | BUSH | LED40127HDCNT | DIGIQUEST | DGQ24169HDR |
| AKAI | AL4012SMART | AUTOVOX | AX24LED70 | BUSH | LED43292UHDFVPHDR | DIGIQUEST | DGQ28169HDR |
| AKAI | AL4222SMART | AUTOVOX | AX26DDV68 | BUSH | LED49292UHDFVPHDR | DIGIQUEST | DGQ28EDGE |
| AKAI | AL4275SMART | AUTOVOX | AX26LED70 | BUSH | RC1541 | DIGIQUEST | DGQ32169HDR |
| AKAI | ALED1905T | AUTOVOX | AX26LED73 | BUSH | RC1543-1541 | DIGIQUEST | DGQ32DLHR |
| AKAI | ALED1905TBK | AUTOVOX | AX26TFT05 | BUSH | RC1546-1542 | DIGIQUEST | DGQ40169FHD |
| AKAI | ALED1906TBK | AUTOVOX | AX26TFT05S | BUSH | RC1602(V2) | DIGIQUEST | DGQ40FHD |
| AKAI | ALED1907TBK | AUTOVOX | AX26TFT16 | CELCUS | 32882HDLCD | DIKOM | DK19955B19 |
| AKAI | ALED1912TBK | AUTOVOX | AX26TFTB26 | CLATRONIC | CTC1405TX | DIKOM | DK19955B29C10 |
| AKAI | ALED1914BK | AUTOVOX | AX26UDV70 | CLATRONIC | CTC2005TX | DIKOM | DK22137B19F |
| AKAI | ALED19M1BK | AUTOVOX | AX27TFT05S | CLATRONIC | CTC2105TX | DIKOM | DK22137B29FC10 |
| AKAI | ALED2022BK | AUTOVOX | AX28Q05S | CLATRONIC | CTC4200PLASMA | DIKOM | DK22182B30FC10 |
| AKAI | ALED2212TBK | AUTOVOX | AX30TFT05S | CLATRONIC | LCDCOSMO1510 | DIKOM | DK24114830C10 |
| AKAI | ALED2222WE | AUTOVOX | AX30TFTB26 | CLATRONIC | VMB1110 | DIKOM | DK24280B30C10E |
| AKAI | ALED22MBK | AUTOVOX | AX32DDT08N | CMREMOTES | 90016511 | DIKOM | DK32125B30C10U |
| AKAI | ALED2405T | AUTOVOX | AX32DDV68 | CMREMOTES | 90122820 | DIKOM | DK32167B29C10U |
| AKAI | ALED2409TBK | AUTOVOX | AX32LED70 | CMREMOTES | 90506910 | DIKOM | DK32167B30C10 |
| AKAI | ALED2409TWE | AUTOVOX | AX32LED70N | CONTIN.EDISON | CEBLED32HD3 | DIKOM | DK32280B30C10D |
| AKAI | ALED2412 | AUTOVOX | AX32LED72 | CONTIN.EDISON | CELED321883 | DIKOM | DK39167N25FC10 |
| AKAI | ALED2414BK | AUTOVOX | AX32TFT05S | CONTIN.EDISON | CELED32ML3 | DIKOM | DK40280N25F1C10D |
| AKAI | ALED2422BK | AUTOVOX | AX32TFT16 | CONTIN.EDISON | CELED32SDDS3 | DIKOM | DK50182S16FC10ELED |
| AKAI | ALED2422WE | AUTOVOX | AX32TFTB26 | CONTIN.EDISON | CELED1853 | DUALTEC | CTVD1010 |
| AKAI | ALED2424BK | AUTOVOX | AX32UDV70 | CONTIN.EDISON | CELED191803 | DUALTEC | DTFT7202 |
| AKAI | ALED2606TBK | AUTOVOX | AX32UDV70N | CONTIN.EDISON | CELED215HD2 | DUALTEC | DTFT7203 |
| AKAI | ALED2609TBK | AUTOVOX | AX32UDV73HD | CONTIN.EDISON | CELED320716B3 | DUALTEC | TVL202L |
| AKAI | ALED2609TWE | AUTOVOX | AX37TFT16 | CONTIN.EDISON | CELED32B3 | DUALTEC | TVP4201 |
| AKAI | ALED2809TBK | AUTOVOX | AX40TFT16 | CONTIN.EDISON | CELED32HD3 | EI | 511000SD |
| AKAI | ALED2809TWE | AUTOVOX | AX42P04S | CONTIN.EDISON | CELED32SMARTB3 | EI | 511000SD(v2) |

| | |
|------------|---------------|
| EI | 51100TX1 |
| EI | 51100TXT(v2) |
| EI | 51400SD |
| EI | 51400SD(v2) |
| EI | 51400TX |
| EI | 51400TXT(v2) |
| EI | EXCLUSIVE(v2) |
| ELBE | 21RF105 |
| ELBE | XTV1912TDT |
| ELBE | XTV1913TDT |
| ELBE | XTV1914USB |
| ELBE | XTV1915LED |
| ELBE | XTV1923 |
| ELBE | XTV2065 |
| ELBE | XTV2204USB |
| ELBE | XTV2205TDT |
| ELBE | XTV2206USB |
| ELBE | XTV2266USB |
| ELBE | XTV2405LED |
| ELBE | XTV2407LED |
| ELBE | XTV2650TDT |
| ELBE | XTV2655TDT |
| ELBE | XTV2656TDT |
| ELBE | XTV3280TDT |
| ELBE | XTV3291LED |
| ELBE | XTV4090WIFI |
| ELBE | XTV5050WIFI |
| ELBE | XTV5500WIFI |
| ELBE | XTV5501WIFI |
| ESSENTIELB | 43UHDF600SM |
| ESSENTIELB | 43UHDSMART |
| ESSENTIELB | 50UHDSMART |
| ESSENTIELB | 52UHDF600SM |
| ESSENTIELB | 55UHDF600SM |
| ESSENTIELB | 55UHDSMART |
| ESSENTIELB | KEA24VHSMART |
| ESSENTIELB | KEA32WGSMART |
| ESSENTIELB | KEA32VHSMART |
| ESSENTIELB | "LUGANO22" |
| ESSENTIELB | "MELIA26" |
| ESSENTIELB | "VELINIO24" |
| ESTAR | LEDTV19D1T1 |
| ESTAR | LEDTV22D1T1 |
| ESTAR | LEDTV22D4T2 |
| ESTAR | LEDTV24D1T1 |
| ESTAR | LEDTV24D3T2 |
| ESTAR | LEDTV24D4T2 |
| ESTAR | LEDTV29D1T1 |
| ESTAR | LEDTV32D1T1 |
| ESTAR | LEDTV32D3T2 |
| ESTAR | LEDTV32D4T2 |
| ESTAR | LEDTV32D5T2 |
| ESTAR | LEDTV40D4T2 |
| EUROVISION | 4205BIT |
| EUROVISION | LCD1507 |
| EUROVISION | LCD2007 |
| EUROVISION | LCD2700 |
| EUROVISION | LCD2707 |
| EUROVISION | LCD3207 |
| EUROVISION | LCD3710 |
| EUROVISION | TVLCD2700 |
| EUROVISION | TX1446 |
| EXCLUSIV | EX32D11TS |
| EXCLUSIV | LE2219 |
| EXCLUSIV | LE3222TS |
| F&U | 19891MP4 |
| F&U | F719 |
| F&U | FDH22882 |
| F&U | FDH26882 |
| F&U | FL16101 |
| F&U | FL19101 |
| F&U | FL20300 |
| F&U | FL20691 |
| F&U | FL22103 |
| F&U | FL22750 |
| F&U | FL22750(V2) |
| F&U | FL23150 |
| F&U | FL24050 |
| F&U | FL24101 |
| F&U | FL24103 |
| F&U | FL24104 |
| F&U | FL24106 |
| F&U | FL24107 |
| F&U | FL24108 |
| F&U | FL24110 |
| F&U | FL24113 |
| F&U | FL243340 |
| F&U | FL24334P |
| F&U | FL24897WH |
| F&U | FL24902 |
| F&U | FL26750 |
| F&U | FL28101 |
| F&U | FL28107 |

| | |
|----------|--------------|
| F&U | FL28108M |
| F&U | FL28333 |
| F&U | FL28334 |
| F&U | FL28409 |
| F&U | FL2D4305UH |
| F&U | FL2D4306UH |
| F&U | FL2D4307UH |
| F&U | FL2D4308UH |
| F&U | FL2D4903UH |
| F&U | FL2D4904UH |
| F&U | FL2D5004UH |
| F&U | FL2D5504UH |
| F&U | FL2D5505UH |
| F&U | FL2D5506UH |
| F&U | FL2D5805UH |
| F&U | FL2D6503UH |
| F&U | FL2D6504UH |
| F&U | FL2D7503UH |
| F&U | FL2D7504UH |
| F&U | FL32103 |
| F&U | FL32107 |
| F&U | FL32109 |
| F&U | FL32110 |
| F&U | FL32111 |
| F&U | FL32201 |
| F&U | FL32202S |
| F&U | FL32205H |
| F&U | FL32222 |
| F&U | FL32280WH |
| F&U | FL32406P |
| F&U | FL32408 |
| F&U | FL32409 |
| F&U | FL32410 |
| F&U | FL32500 |
| F&U | FL32600S |
| F&U | FL32750H |
| F&U | FL32892 |
| F&U | FL32893P |
| F&U | FL32894WHP |
| F&U | FL32896WH |
| F&U | FL39201 |
| F&U | FL39333 |
| F&U | FL40101 |
| F&U | FL40103 |
| F&U | FL40107 |
| F&U | FL40109 |
| F&U | FL40224P |
| F&U | FL40334 |
| F&U | FL42103 |
| F&U | FL43101 |
| F&U | FLA3220 |
| F&U | FLA3221H |
| F&U | FLA3230WH |
| F&U | FLA4320UH |
| F&U | FLA4350UHWH |
| F&U | FLA5020UH |
| F&U | FLA5520UH |
| F&U | FLA5820UH |
| F&U | FLA6520UH |
| F&U | FLA7520UH |
| F&U | FLED16891 |
| F&U | FLED16891MP4 |
| F&U | FLS32212 |
| F&U | FLS32214H |
| F&U | FLS32215 |
| F&U | FLS32216H |
| F&U | FLS32217H |
| F&U | FLS32218 |
| F&U | FLS32219H |
| F&U | FLS32220H |
| F&U | FLS32221 |
| F&U | FLS32287WH |
| F&U | FLS39202 |
| F&U | FLS39203 |
| F&U | FLS40112 |
| F&U | FLS40201 |
| F&U | FLS43205 |
| F&U | FLS43206 |
| F&U | FLS43207 |
| F&U | FLS43286WH |
| F&U | FLS43287WH |
| F&U | FLS49201 |
| F&U | FLS50201 |
| F&U | FLS50222 |
| FAIRTEC | FC322T33 |
| FENNER | FTV20THB |
| FENNER | FTV42PL |
| FERGUSON | 22F7030 |
| FINLUX | 15FLN745 |
| FINLUX | 15FLND745 |
| FINLUX | 16FLD910L |
| FINLUX | 16FLD910LD |
| FINLUX | 16FLX914LU |

| | |
|--------|-------------------|
| FINLUX | 19FLD905SLU |
| FINLUX | 19FLY851VUD |
| FINLUX | 19FLY905LU |
| FINLUX | 19FLY910LVD |
| FINLUX | 19WFL760 |
| FINLUX | 19WFLD760 |
| FINLUX | 20WFLD745 |
| FINLUX | 22FLHX905VU |
| FINLUX | 22FLHY905LVD |
| FINLUX | 22FLHYR905LVD |
| FINLUX | 22FLX850U |
| FINLUX | 22FLY850VUD |
| FINLUX | 22FLY851VUD |
| FINLUX | 22FLY852VUD |
| FINLUX | 22FLYR850VUD |
| FINLUX | 26FL760P |
| FINLUX | 26FLD755 |
| FINLUX | 26FLD760P |
| FINLUX | 26FLD785 |
| FINLUX | 26FLD905 |
| FINLUX | 26FLYR916LHU |
| FINLUX | 32FDL745 |
| FINLUX | 32FHB4100 |
| FINLUX | 32FL760P |
| FINLUX | 32FL800P |
| FINLUX | 32FLD755 |
| FINLUX | 32FLD760 |
| FINLUX | 32FLD760P |
| FINLUX | 32FLD785 |
| FINLUX | 32FLD800 |
| FINLUX | 32FLD845H |
| FINLUX | 32FLD862H |
| FINLUX | 32FLD905H |
| FINLUX | 32FLE850H |
| FINLUX | 32FLHD760 |
| FINLUX | 32FLHXR850HU |
| FINLUX | 32FLHY850HU |
| FINLUX | 32FLHYR850HU |
| FINLUX | 32FLXR850HU |
| FINLUX | 32FLY845HU |
| FINLUX | 32FLYR850HU |
| FINLUX | 32FLYR850VHU |
| FINLUX | 32HPD274BT |
| FINLUX | 32LXY845HU |
| FINLUX | 37FL760P |
| FINLUX | 37FLD785P |
| FINLUX | 37FLH745 |
| FINLUX | 37FLH760 |
| FINLUX | 37FLHD745 |
| FINLUX | 37FLHD760 |
| FINLUX | 37FLHD785 |
| FINLUX | 40FLHY882U |
| FINLUX | 42FL760P |
| FINLUX | 42FL800P |
| FINLUX | 42FLD760 |
| FINLUX | 42FLD760P |
| FINLUX | 42FLD785 |
| FINLUX | 42FLD785P |
| FINLUX | 42FLD800 |
| FINLUX | 42FLD800P |
| FINLUX | 42FLH745 |
| FINLUX | 42FLH760 |
| FINLUX | 42FLH800 |
| FINLUX | 42FLHD745 |
| FINLUX | 42FLHD760 |
| FINLUX | 42FLHD760TC |
| FINLUX | 42FLHD785 |
| FINLUX | 42FLHD800 |
| FINLUX | 42FLHYR841U |
| FINLUX | 42FLHYR905HU |
| FINLUX | 46FLHXR882HU |
| FINLUX | 46FLHY882 |
| FINLUX | 46FLHYR882U |
| FINLUX | 47FLHD760 |
| FINLUX | 50FPHD05 |
| FINLUX | 50FUB5522 |
| FINLUX | 6Y71DXNWBWHPDP |
| FINLUX | FX16910B17LEDSLIM |
| FINLUX | FX19850N15 |
| FINLUX | FX19905B17LEDSLIM |
| FINLUX | FX22850N15 |
| FINLUX | FX22905B17LEDSLIM |
| FINLUX | FX22905B19FLED |
| FINLUX | FX24507S27YXB |
| FINLUX | FX24551S27YXE |
| FINLUX | FX26850N13 |
| FINLUX | FX32269B40Q2D |
| FINLUX | FX32269S27YXD |
| FINLUX | FX32551B40Q2D |
| FINLUX | FX32850S8 |
| FINLUX | FX32905B17FHLED |
| FINLUX | FX39269S27YXH |

| | |
|-----------|------------------|
| FINLUX | FX40269S27YXH |
| FINLUX | FX42850 |
| FINLUX | FX42910B16F1HLED |
| FINLUX | FX43551B40Q2H |
| FINLUX | FX46882 |
| FINLUX | FX46905B16F1HLED |
| FINLUX | FX49269B40Q2P |
| FINLUX | FX49296B40Q2P |
| FINLUX | FX50296S31Y2P |
| FINLUX | FX55292B40Q2P |
| FINLUX | FX55292S31Y2P |
| FINLUX | FX55990P4F1HLED |
| FINLUX | RC5110 |
| FIRSTLINE | 42VST30 |
| FIRSTLINE | FS1505VE |
| FIRSTLINE | FS21505VE |
| FIRSTLINE | PFL4205 |
| FORCE | 4205 |
| FORCE | LT1506LCD |
| FORCE | PT4205 |
| FORMENTI | AT24226B30C10 |
| FUEGO | 42FG3700LZT2 |
| FUJITSU | FDH1988W |
| FUNAI | 14A0810 |
| FUNAI | 20A1100 |
| FUNAI | 20A1110 |
| FUNAI | 30A0829WAL |
| FUNAI | FDH26882H |
| GERMANVOX | TV14Q247 |
| GERMANVOX | TV14Q249 |
| GERMANVOX | TV20Q228001 |
| GOODMANS | LD1501 |
| GOODMANS | LD2655HD |
| GOODMANS | LD3255HD |
| GOODMANS | LD3261HDFVT |
| GOODMANS | LD3755HD |
| GOODMANS | LD3761HDFVT |
| GOODMANS | LD4255HD |
| GOODMANS | LD4260HDFVT |
| GOODMANS | TVG149T |
| GOODMANS | TVG209T |
| GOODMANS | TVG2195L |
| GOODMANS | TVG219T |
| GOODMANS | TVG219T/SL |
| GORENJE | ARTLINE(v2) |
| GORENJE | ATLANTA(v2) |
| GORENJE | DISCOVERY(v2) |
| GORENJE | MARINER(v3) |
| GORENJE | MEDIALINE(v2) |
| GORENJE | MERCURY(v3) |
| GORENJE | ORBITER(v3) |
| GORENJE | SOFTLINE(v3) |
| GORENJE | VOYAGER(v4) |
| GRAETZ | GR20E1000 |
| GRAETZ | GR22E2200 |
| GRAETZ | GR24E2400 |
| GRAETZ | GR32E3200 |
| GRAETZ | GR32E3200D |
| GRAETZ | GR32E33000 |
| GRAETZ | GR40E4200 |
| GRAETZ | GR50E5200 |
| GRAETZ | LE2419DTS |
| GRANDIN | 20LCD01 |
| GRANDIN | 26LVHD051 |
| GRANDIN | 32LVHD051 |
| GRANDIN | 42PV0705 |
| GRANDIN | 42PVN05 |
| GRANDIN | 55PMT07 |
| GRUNKEL | 14G3T |
| GRUNKEL | G3209 |
| GRUNKEL | T1911BHDTV |
| GRUNKEL | T3211BHDTV |
| HAIER | LDF39V100 |
| HAIER | LDF40V100 |
| HAIER | LDF40V150 |
| HAIER | LDF40V280 |
| HAIER | LDF40V280S |
| HAIER | LDF40V80 |
| HAIER | LDF46V180 |
| HAIER | LDF50V500S |
| HAIER | LDH32V100 |
| HAIER | LDH32V100B |
| HAIER | LDH32V150 |
| HAIER | LDU75V900S |
| HAIER | LEF22V150 |
| HAIER | LEF32V200 |
| HAIER | LEF40V200SB |
| HAIER | LEF42V200 |
| HAIER | LEF48V200 |
| HAIER | LEF48V300 |
| HAIER | LEF49V600S |
| HAIER | LEF55V300 |
| HAIER | LEF65V200 |

| | |
|---------|----------------|
| HAIER | LEP24V100 |
| HAIER | LEH28V100 |
| HAIER | LEH32V200 |
| HAIER | LEU43V300S |
| HAIER | LEU49V300S |
| HAIER | LEU49XS4K |
| HAIER | LEU55V800S |
| HAIER | LEU65V1000S |
| HAIER | U49H7000 |
| HITACHI | 15LD2200 |
| HITACHI | 15LD2250B |
| HITACHI | 15LD2550B |
| HITACHI | 15LD3200(V2) |
| HITACHI | 15LD3200(V2) |
| HITACHI | 17LD4220 |
| HITACHI | 19H8S02R |
| HITACHI | 19HL8L02R |
| HITACHI | 19LD2550B |
| HITACHI | 22H8S03R |
| HITACHI | 22HBC06I |
| HITACHI | 22HBC06UB |
| HITACHI | 22HE1311 |
| HITACHI | 22HE1321 |
| HITACHI | 22HL8L03R |
| HITACHI | 22HXC06 |
| HITACHI | 22HYC06 |
| HITACHI | 22LD4200(V2) |
| HITACHI | 22LD4220 |
| HITACHI | 22LD4500UK(V2) |
| HITACHI | 22LE6560U |
| HITACHI | 24H8S03R |
| HITACHI | 24HAE2250 |
| HITACHI | 24HB11J65U |
| HITACHI | 24HB11T65U |
| HITACHI | 24HB11T65U |
| HITACHI | 24HB1J65U |
| HITACHI | 24HB1T65U |
| HITACHI | 24HB1W05A |
| HITACHI | 24HBC05 |
| HITACHI | 24HBJ55U |
| HITACHI | 24HBT55U |
| HITACHI | 24HE1000 |
| HITACHI | 24HE1311 |
| HITACHI | 24HE1510 |
| HITACHI | 24HE1710 |
| HITACHI | 24HE2320 |
| HITACHI | 24HE2410 |
| HITACHI | 24HL8L03R |
| HITACHI | 24HXC05 |
| HITACHI | 24HXJ15U |
| HITACHI | 24HXT15U |
| HITACHI | 24HYC05I |
| HITACHI | 26H8L02 |
| HITACHI | 26LD2550B |
| HITACHI | 26LD6200 |
| HITACHI | 26LD6200(V2) |
| HITACHI | 26LD6200A(V2) |
| HITACHI | 26LD6600B(V2) |
| HITACHI | 26LD6600C(V2) |
| HITACHI | 28HXC05 |
| HITACHI | 28HXJ15U |
| HITACHI | 28HXT15U |
| HITACHI | 28LD6200 |
| HITACHI | 28LD6200(V2) |
| HITACHI | 32H8L02R |
| HITACHI | 32H8S02 |
| HITACHI | 32H8S03R |
| HITACHI | 32HAE2250 |
| HITACHI | 32HAE2252 |
| HITACHI | 32HAE4250 |
| HITACHI | 32HAE4252 |
| HITACHI | 32HAK2250 |
| HITACHI | 32HAK4250 |
| HITACHI | 32HB16J61U |
| HITACHI | 32HB16T61U |
| HITACHI | 32HB1C06I |
| HITACHI | 32HB1J46U |
| HITACHI | 32HB1S66I |
| HITACHI | 32HB1T06I |
| HITACHI | 32HB1T46U |
| HITACHI | 32HB1W05 |
| HITACHI | 32HB2W |
| HITACHI | 32HB2W66I |
| HITACHI | 32HB6J41U |
| HITACHI | 32HB6J61U |
| HITACHI | 32HB6T41U |
| HITACHI | 32HB6T51U |
| HITACHI | 32HB6T61U |
| HITACHI | 32HBC01 |
| HITACHI | 32HE1000 |
| HITACHI | 32HE1100 |
| HITACHI | 32HE1321 |
| HITACHI | 32HE1410 |
| HITACHI | 32HE1500 |

| | |
|---------|--------------|
| HITACHI | 32HE1510 |
| HITACHI | 32HE1710 |
| HITACHI | 32HE3000 |
| HITACHI | 32HXC01 |
| HITACHI | 32HXC02 |
| HITACHI | 32HXC05 |
| HITACHI | 32HXT16U |
| HITACHI | 32HYC01I |
| HITACHI | 32HYTD1L |
| HITACHI | 32HZC66 |
| HITACHI | 32HZT66T |
| HITACHI | 32LD6200 |
| HITACHI | 32LD6200(V2) |
| HITACHI | 36LD6200 |
| HITACHI | 36LD6200(V2) |
| HITACHI | 39HXC02 |
| HITACHI | 40H6C03 |
| HITACHI | 40H6L03 |
| HITACHI | 40HB1C06I |
| HITACHI | 40HB1C66I |
| HITACHI | 40HB6T62H |
| HITACHI | 40HBT42A |
| HITACHI | 40HE1321 |
| HITACHI | 40HE1511 |
| HITACHI | 40HE3000 |
| HITACHI | 40HE3621 |
| HITACHI | 40HXC06 |
| HITACHI | 40HXT16U |
| HITACHI | 40HYC42 |
| HITACHI | 42HBT42UK |
| HITACHI | 42HXT12U |
| HITACHI | 42HZC663D |
| HITACHI | 42HZC66T3D |
| HITACHI | 42HZT66K |
| HITACHI | 42HZT66T |
| HITACHI | 43HAE4251 |
| HITACHI | 43HAE4252 |
| HITACHI | 43HAK5750 |
| HITACHI | 43HAK5751 |
| HITACHI | 43HAK6100 |
| HITACHI | 43HAK6151 |
| HITACHI | 43HAK7150V2 |
| HITACHI | 43HBT42A |
| HITACHI | 43HE3000 |
| HITACHI | 43HG6W69I |
| HITACHI | 43HK6T74U |
| HITACHI | 43HL7000 |
| HITACHI | 46H8L01 |
| HITACHI | 46H8L03 |
| HITACHI | 48HB6T62U |
| HITACHI | 48HB6T72U |
| HITACHI | 48HBT62U |
| HITACHI | 48HBT62UH |
| HITACHI | 49HAK5750 |
| HITACHI | 49HAK7150V2 |
| HITACHI | 49HG6W69I |
| HITACHI | 50HAK5750 |
| HITACHI | 50HAK5751 |
| HITACHI | 50HAK6100 |
| HITACHI | 50HAK6151 |
| HITACHI | 50HAL7250 |
| HITACHI | 50HB16T72U |
| HITACHI | 50HB6T72U |
| HITACHI | 50HXC66 |
| HITACHI | 50HXT16U |
| HITACHI | 50HZT66K |
| HITACHI | 55HAK5750 |
| HITACHI | 55HAK5751 |
| HITACHI | 55HAK6100 |
| HITACHI | 55HAK6151 |
| HITACHI | 55HAK7150V2 |
| HITACHI | 55HAL7250 |
| HITACHI | 55HB16T72U |
| HITACHI | 55HB6T62U |
| HITACHI | 55HB6T72U |
| HITACHI | 55HG2W69I |
| HITACHI | 55HG6W69I |
| HITACHI | 55HZ6C66I |
| HITACHI | 58HAK5750 |
| HITACHI | 58HAK5751 |
| HITACHI | 58HAK6151 |
| HITACHI | 58HAK6151 |
| HITACHI | 58HAK5751 |
| HITACHI | 58HAK6100 |
| HITACHI | 58HAK6151 |
| HITACHI | 58HAK7150V2 |
| HITACHI | 58HAL7250 |
| HITACHI | 58HZW66 |
| HITACHI | 75HAK7150V2 |
| HITACHI | C2126S |
| HITACHI | C28W460N |
| HITACHI | C28WF560N |
| HITACHI | CL28W460AN |
| HITACHI | CL29F60N |

| | |
|-----------|---------------|
| HITACHI | L19DG07U |
| HITACHI | L19DK04U |
| HITACHI | L19DP04U |
| HITACHI | L22DG07U |
| HITACHI | L22DK04U |
| HITACHI | L22DP04E |
| HITACHI | L22DP04U |
| HITACHI | L22DP04UA |
| HITACHI | L22DP04UH |
| HITACHI | L22H01 |
| HITACHI | L22VG07U |
| HITACHI | L26DP04U |
| HITACHI | L26DP04UA |
| HITACHI | L26DP04UB |
| HITACHI | L32HC04U |
| HITACHI | L32VG08U |
| HOHER | H15LX90D |
| HOHER | H19LX700DR |
| HOHER | H19LX810DVD |
| HOHER | H22LX810DVD |
| HOHER | H26LX600D |
| HOHER | H32LX350D |
| HOHER | H32LX600D |
| HOHER | H42P20 |
| HOHER | PL42SI |
| HOSHI | HS1406 |
| HYPSON | HR55 |
| HYPSON | HRF55 |
| HYPSON | HY2610 |
| HYPSON | HY3220HDI |
| HYPSON | HY3710 |
| HYPSON | HY3710SCD |
| HYPSON | HYP19TNTHDM |
| HYUNDAI | CTV14227MN |
| HYUNDAI | CTV14227N |
| HYUNDAI | CTV14327MN |
| HYUNDAI | CTV1438MN |
| HYUNDAI | CTV2007MN |
| HYUNDAI | CTV2133MN |
| HYUNDAI | CTV2141MP |
| HYUNDAI | HLB1510 |
| HYUNDAI | HLT008 |
| HYUNDAI | HLT2008 |
| HYUNDAI | HLT3008 |
| HYUNDAI | HN24E28H |
| HYUNDAI | HN24EN4H |
| HYUNDAI | HN32E28H |
| HYUNDAI | HN32EF2H |
| HYUNDAI | HPT4205 |
| IINN | 19013EL |
| IINN | 22013EL |
| IINN | 24013EL |
| IJOY | ILED19SG803 |
| IJOY | ILED24S8802 |
| IJOY | ILED24SG802V2 |
| IJOY | ILED32SG802V2 |
| IJOY | LUX9119 |
| INEXIVE | 39800I |
| INEXIVE | 49800I |
| INFINITON | INTV22M303 |
| INFINITON | INTV3217 |
| INFINITON | INTV32LS330 |
| INFINITON | INTV32M302 |
| INFINITON | INTV40M510 |
| INFINITON | INTV43SU1200 |
| INFINITON | INTV55LU1800 |
| INFINITON | INTV75SU1800 |
| INNOHIT | 20TX |
| INNOHIT | "27"LCD" |
| INNOHIT | DV3HDREADY |
| INNOHIT | FH052040602GP |
| INNOHIT | FH09041600976 |
| INNOHIT | HT2610 |
| INNOHIT | "H15"LCD" |
| INNOHIT | IH15015 |
| INNOHIT | IH1505 |
| INNOHIT | IH1506 |
| INNOHIT | IH1510 |
| INNOHIT | IH1515 |
| INNOHIT | IH1518LS |
| INNOHIT | IH1538 |
| INNOHIT | IH1579ST |
| INNOHIT | IH15950TV |
| INNOHIT | IH1596COMBO |
| INNOHIT | IH16820T |
| INNOHIT | IH16820T11B |
| INNOHIT | IH16820T9N |
| INNOHIT | IH16820TD9N |
| INNOHIT | IH16914T17B |
| INNOHIT | "H17"LCD" |
| INNOHIT | IH19796W |
| INNOHIT | IH19820T11B |
| INNOHIT | IH19820T17B |

| | |
|---------|--------------------|
| INNOHIT | IH19820T17N |
| INNOHIT | IH19855TD11B |
| INNOHIT | IH19855TWD |
| INNOHIT | IH19855WT |
| INNOHIT | IH19860T |
| INNOHIT | IH19860T17BH |
| INNOHIT | IH19875TWD |
| INNOHIT | IH19882T11B |
| INNOHIT | IH19884LED |
| INNOHIT | IH19884T9N |
| INNOHIT | IH19885WT |
| INNOHIT | IH19914T17B |
| INNOHIT | IH19914T17BLEDSLIM |
| INNOHIT | IH19914T19B |
| INNOHIT | IH19916T17BH |
| INNOHIT | IH19916T19BLEDSLIM |
| INNOHIT | IH1995W |
| INNOHIT | IH200 |
| INNOHIT | IH2007 |
| INNOHIT | IH2009 |
| INNOHIT | IH2015(1*V) |
| INNOHIT | IH2016 |
| INNOHIT | IH20715 |
| INNOHIT | IH20725T |
| INNOHIT | IH20765 |
| INNOHIT | IH20884 |
| INNOHIT | IH20884T |
| INNOHIT | IH20LCD |
| INNOHIT | IH21325T |
| INNOHIT | IH22820T |
| INNOHIT | IH22820TWTX |
| INNOHIT | IH22843T17BFH |
| INNOHIT | IH22843TD15NF |
| INNOHIT | IH22856T11B |
| INNOHIT | IH22860TWD |
| INNOHIT | IH22860TWT |
| INNOHIT | IH22875TWD |
| INNOHIT | IH22875WD |
| INNOHIT | IH22875WT |
| INNOHIT | IH22884T11 |
| INNOHIT | IH22910TD17BF |
| INNOHIT | IH22911T17BF |
| INNOHIT | IH22911T19B |
| INNOHIT | IH22911T19BF |
| INNOHIT | IH22914T17BFH |
| INNOHIT | IH22914T19B |
| INNOHIT | IH22915T17B |
| INNOHIT | IH22916T17B |
| INNOHIT | IH2295T |
| INNOHIT | IH2310 |
| INNOHIT | IH23910T17BFH |
| INNOHIT | IH24884T11F |
| INNOHIT | IH24916T17B |
| INNOHIT | IH24916T19B |
| INNOHIT | IH24916TD17BF |
| INNOHIT | IH2607 |
| INNOHIT | IH26750T |
| INNOHIT | IH26783 |
| INNOHIT | IH26847T17BH |
| INNOHIT | IH26855T(v1) |
| INNOHIT | IH26855T14BF |
| INNOHIT | IH26860T |
| INNOHIT | IH26860T17B |
| INNOHIT | IH26875T12N |
| INNOHIT | IH26916T17B |
| INNOHIT | IH27LCD |
| INNOHIT | IH3007 |
| INNOHIT | IH3207 |
| INNOHIT | IH32130T |
| INNOHIT | IH3215(v1) |
| INNOHIT | IH3216 |
| INNOHIT | IH32700 |
| INNOHIT | IH32745T |
| INNOHIT | IH32750 |
| INNOHIT | IH32781T |
| INNOHIT | IH32783T |
| INNOHIT | IH32843T19BF |
| INNOHIT | IH32855T |
| INNOHIT | IH32860T16BFH |
| INNOHIT | IH32860T17B |
| INNOHIT | IH32860T19B |
| INNOHIT | IH32875T(V1) |
| INNOHIT | IH32882T |
| INNOHIT | IH32883T16B |
| INNOHIT | IH32884T19B |
| INNOHIT | IH32884WT |
| INNOHIT | IH32900T16B |
| INNOHIT | IH32905T16B |
| INNOHIT | IH32910T17BFH |
| INNOHIT | IH32916T16BH |
| INNOHIT | IH32980T17N |
| INNOHIT | IH32LCD |
| INNOHIT | IH3710 |

| | |
|-----------|--------------|
| INNOHIT | IH377831 |
| INNOHIT | IH4025 |
| INNOHIT | IH40781T |
| INNOHIT | IH40910T15NF |
| INNOHIT | IH4205 |
| INNOHIT | IH42781T |
| INNOHIT | IH49 |
| INNOHIT | IH5125 |
| INNOHIT | PDP4200 |
| INNOHIT | RF2916 |
| INNOHIT | RF2985ST/TX |
| IRRADIO | TV1241 |
| IRRADIO | XTV2420HD |
| IRRADIO | XTV2820HD |
| ITALTV | 32EL8001H |
| ITT/NOKIA | 22LT411 |
| ITT/NOKIA | 22LT475CD |
| ITT/NOKIA | 26LT30 |
| ITT/NOKIA | 26LT455C |
| ITT/NOKIA | 26LT475CD |
| ITT/NOKIA | 32LT30 |
| ITT/NOKIA | 32LT31 |
| ITT/NOKIA | 32LT33 |
| ITT/NOKIA | 32LT34 |
| ITT/NOKIA | 32LT511 |
| ITT/NOKIA | 32LT555C |
| ITT/NOKIA | 32LT601B |
| ITT/NOKIA | 32LT655C |
| ITT/NOKIA | 42LT601B |
| ITT/NOKIA | 42LT655C |
| ITT/NOKIA | ASL22943 |
| ITT/NOKIA | ASL22960 |
| ITT/NOKIA | ASL24960 |
| ITT/NOKIA | ASL32920 |
| ITT/NOKIA | ASL32921 |
| ITT/NOKIA | ASL32960 |
| ITT/NOKIA | ASL39920 |
| ITT/NOKIA | ASL39970 |
| ITT/NOKIA | ASL48990 |
| ITT/NOKIA | GR1505TFT |
| ITT/NOKIA | GR16820T |
| ITT/NOKIA | GR19860T |
| ITT/NOKIA | GR2000 |
| ITT/NOKIA | GR2006 |
| ITT/NOKIA | GR20725T |
| ITT/NOKIA | GR20E1000 |
| ITT/NOKIA | GR21135TXX |
| ITT/NOKIA | GR2123TX |
| ITT/NOKIA | GR22880T |
| ITT/NOKIA | GR22E2200 |
| ITT/NOKIA | GR24E2400 |
| ITT/NOKIA | GR2608 |
| ITT/NOKIA | GR28135TXX |
| ITT/NOKIA | GR32E3200 |
| ITT/NOKIA | GR32E3200D |
| ITT/NOKIA | GR32E3300D |
| ITT/NOKIA | GR3710 |
| ITT/NOKIA | GR3710GRAETZ |
| ITT/NOKIA | GR40E4200 |
| ITT/NOKIA | GR4205 |
| ITT/NOKIA | GR4205GRAETZ |
| ITT/NOKIA | GR50E5200 |
| ITT/NOKIA | LD265301DB |
| ITT/NOKIA | LE2419DTS |
| ITT/NOKIA | LT153500DB |
| ITT/NOKIA | LT19350DB |
| ITT/NOKIA | LT193500DB |
| ITT/NOKIA | LT223560B |
| ITT/NOKIA | LT26354DB |
| ITT/NOKIA | LT263590B |
| ITT/NOKIA | LT26360FD84 |
| ITT/NOKIA | LT3223510BH |
| ITT/NOKIA | LT32350 |
| ITT/NOKIA | LT32352AB |
| ITT/NOKIA | LT32353AB |
| ITT/NOKIA | LT32359FD8 |
| ITT/NOKIA | LTV32359FAGB |
| ITT/NOKIA | SL19912 |
| ITT/NOKIA | SL19940 |
| ITT/NOKIA | SL19LD910 |
| ITT/NOKIA | SL22912 |
| ITT/NOKIA | SL22940 |
| ITT/NOKIA | SL22942 |
| ITT/NOKIA | SL22LD910 |
| ITT/NOKIA | SL24940 |
| ITT/NOKIA | SL24942 |
| ITT/NOKIA | SL24944 |
| ITT/NOKIA | SL24960 |
| ITT/NOKIA | SL26856FS |
| ITT/NOKIA | SL26912 |
| ITT/NOKIA | SL26940 |
| ITT/NOKIA | SL26LT843 |
| ITT/NOKIA | SL32132 |

| | |
|-----------|-------------------|
| ITT/NOKIA | SL32912 |
| ITT/NOKIA | SL32914 |
| ITT/NOKIA | SL32915 |
| ITT/NOKIA | SL32940 |
| ITT/NOKIA | SL32942 |
| ITT/NOKIA | SL32LT843 |
| ITT/NOKIA | SL42914 |
| ITT/NOKIA | SL42940 |
| ITT/NOKIA | SL42942 |
| ITT/NOKIA | SL42960 |
| ITT/NOKIA | SL42LT843 |
| ITT/NOKIA | SL46940 |
| ITT/NOKIA | SL55900 |
| JQ | LTVJQ1502 |
| JVC | LT24VH43B |
| JVC | LT32VFSQ52I |
| JVC | LT32VH43B |
| JVC | LT32VH53B |
| JVC | LT40VF42L |
| JVC | LT40VF43B |
| JVC | LT40VFSQ52I |
| JVC | LT40VGF64 |
| JVC | LT43VA3000 |
| JVC | LT43VA6900 |
| JVC | LT43VA6955 |
| JVC | LT43VA8900 |
| JVC | LT43VF43B |
| JVC | LT49VA8900 |
| JVC | LT50VA3000 |
| JVC | LT50VA6900 |
| JVC | LT55VA3000 |
| JVC | LT55VA6900 |
| JVC | LT55VA8900 |
| JVC | LT58VA6900 |
| JVC | LT65VA6955 |
| JVC | LT65VA8900 |
| KENDO | CTV4816ST/VLCD |
| KENDO | CTV4817ST/VLCD |
| KENDO | CTV4818ST/VLCD |
| KENDO | CTV4820ST/VPLASMA |
| KENDO | LCDTV385150 |
| KENDO | LCDTV665260 |
| KENDO | LCDTV685270 |
| KENDO | PD26S106HD |
| KENDO | PLASMATV106420S |
| KENDO | TL30LC08 |
| KENNEK | KX2005BF |
| KUBO | K3755VTSTHD |
| KUNFT | 22VLM15 |
| KUNFT | 22VLM14 |
| KUNFT | 22VLM15 |
| KUNFT | 24HE1710FTR |
| KUNFT | 24HE2710FTR |
| KUNFT | 24VLM14 |
| KUNFT | 24VLM15 |
| KUNFT | 24VLM18 |
| KUNFT | 24VLM15 |
| KUNFT | 32HE1710FTR |
| KUNFT | 32VDLM15 |
| KUNFT | 32VDLM16 |
| KUNFT | 395VDLM14 |
| KUNFT | 48VDLM17 |
| KUNFT | K3642X22F |
| KUNFT | K3992X24H |
| KUNFT | K4486V32H |
| KUNFT | K4498V40F |
| KUNFT | K4499V49F |
| KUNFT | K5126X22F |
| KUNFT | K5129X24H |
| LAZER | 867922 |
| LAZER | LED1919 |
| LAZER | LZ32700 |
| LAZER | LZ4816I |
| LAZER | LZ49700 |
| LENCO | DVL2694 |
| LG | 155LG0024GB |
| LG | CB20T40X |
| LG | CB20T40X |
| LG | CB21T40X |
| LG | RE28CZ20RX |
| LIFETEC | MD30079 |
| LIFETEC | MD32532 |
| LISTO | 15LCDTNT173 |
| LISTO | 15LCDTNT684 |
| LISTO | 19LCDTNT175 |
| LISTO | 19LCDTNT474 |
| LISTO | 19LCDTNT685 |
| LISTO | 19LCDTNT953(V2) |
| LISTO | 19LCDTNT953(V3) |
| LISTO | 19LCDUSB705 |
| LISTO | 22LCDTNT954 |
| LISTO | 22LCDTNT954(V2) |
| LISTO | 22LCDTNT954(V3) |

| | |
|-----------|------------------|
| LISTO | 22LCDUSB465 |
| LISTO | 2PNT752086 |
| LISTO | 32LCDUSB654 |
| LODOS | SL55 |
| LOGIK | L24HEDN14 |
| LOGIK | L24HEDP14 |
| LOGIK | L24HEDR14 |
| LOGIK | L24HEDW14 |
| LUXOR | LX19841RN15 |
| LUXOR | LX19911RB19 |
| LUXOR | LX22911RB19F |
| LUXOR | LX26950VBT |
| LUXOR | LX32900RB19 |
| LUXOR | LX32912RS8 |
| LUXTRONIC | BTV1436 |
| LUXTRONIC | BTV1441 |
| LUXTRONIC | BTV1467MN |
| LUXTRONIC | BTV2009MN |
| LUXTRONIC | BTV2019MN |
| LUXTRONIC | BTV2117MN |
| LUXTRONIC | BTV2140MR |
| MAGNADYNE | MA32HDT(V2) |
| MANHATTAN | MT1982T10 |
| MANTA | 19LHN38L |
| MANTA | 22LFN37L |
| MANTA | 22LFN38L |
| MANTA | 24LFN37L |
| MANTA | 24LFN38L |
| MANTA | 24LHN39L |
| MANTA | 24LHN99L |
| MANTA | 32LED39L |
| MANTA | 40LFN38L |
| MANTA | 49LUA58L |
| MANTA | LED320E10 |
| MANTA | LED4004 |
| MANTA | LED4206 |
| MANTA | LED92201 |
| MASTER | TL207 |
| MASTER | TL293 |
| MASTER | TL322 |
| MASTER | TL402 |
| MASTER | TL431 |
| MATSUI | 1541 |
| MATSUI | 32MML2205 |
| MATSUI | 32MML3205 |
| MEDION | MD20294DE |
| MEDION | MD21106 |
| MEDION | MD30079 |
| MEDION | MD30234 |
| MEDION | MD30297 |
| MEDION | MD30302 |
| MEDION | MD30653 |
| MEDION | MD30665 |
| MEDION | MD30667 |
| MEDION | MD30769 |
| MEDION | MD30630 |
| MEDION | MD30689 |
| MEDION | MD31358 |
| MEDION | MD32532 |
| MITASHI | MIE032V08 |
| MITSAI | 19VM12 |
| MITSAI | 22LM11 |
| MITSAI | 22VLM12 |
| MITSAI | 22VM12 |
| MITSAI | 32VDLM12 |
| MPMAN | TV32HD2 |
| NEO | LED1912 |
| NEO | LED1960 |
| NEO | LED19965 |
| NEO | LED2201FHD |
| NEO | LED2202FHD |
| NEO | LED2212 |
| NEO | LED22135US |
| NEO | LED2260 |
| NEO | LED2280 |
| NEO | LED2290 |
| NEO | LED2290F |
| NEO | LED23914 |
| NEO | LED2400FHD |
| NEO | LED24180 |
| NEO | LED26180 |
| NEO | LED32165DL |
| NEO | LED32272DL |
| NEO | LED32665FHD |
| NEO | LED36880FHDSMART |
| NEO | TF19884 |
| NEOM | NM3203LCD |
| NEVIR | NVR7019HDN |
| NEVIR | NVR720119HDN |
| NEVIR | NVR720122HDN |
| NEVIR | NVR720126HDN |
| NEVIR | NVR720132HDN |
| NEVIR | NVR720140HDN |

| | |
|----------|------------------|
| NEVIR | NVR720142HDN |
| NEVIR | NVR740032HDN |
| NEVIR | NVR740042HDN |
| NEVIR | NVR740132HDN |
| NEVIR | NVR740324HDN |
| NEVIR | NVR740332HDB |
| NEVIR | NVR740428HDV |
| NEVIR | NVR740740HDN |
| NEVIR | NVR741520HDN |
| NEVIR | NVR741620HDN |
| NEVIR | NVR750219HDB |
| NEVIR | NVR750219HDD8 |
| NEVIR | NVR750219HDDN |
| NEVIR | NVR750219HDN |
| NEVIR | NVR750219HDR |
| NEVIR | NVR750222HDB |
| NEVIR | NVR750222HDD8 |
| NEVIR | NVR750222HDDN |
| NEVIR | NVR750222HDN |
| NEVIR | NVR750222HDR |
| NEVIR | NVR750224HDB |
| NEVIR | NVR750224HDN |
| NEVIR | NVR750224HDR |
| NEVIR | NVR750226HDB |
| NEVIR | NVR750226HDN |
| NEVIR | NVR750226HDR |
| NEVIR | NVR750232HDB |
| NEVIR | NVR750232HDN |
| NEVIR | NVR750232HDNSLIM |
| NEVIR | NVR750240HDN |
| NEVIR | NVR750242HDN |
| NEVIR | NVR750322HDN |
| NEVIR | NVR750324HDN |
| NEVIR | NVR750332HDN |
| NEVIR | NVR750332HDN(V2) |
| NEVIR | NVR750522HDN |
| NEVIR | NVR750724HDN |
| NEVIR | NVR750819HDN |
| NEVIR | NVR750822HD |
| NEVIR | NVR750824HDN |
| NEVIR | NVR751020HDN |
| NEVIR | NVR751219HD |
| NEVIR | NVR751224HD |
| NEXIUS | NXRFX2180VE |
| NGM | 3201 |
| NGM | 5001 |
| NIKKEI | 24H1001 |
| NIKKEI | 24H2001S |
| NIKKEI | 32H1001 |
| NIKKEI | 32H2001S |
| NIKKEI | 39F4001S |
| NIKKEI | NK1581LD |
| NIKKEI | NK16V56L |
| NIKKEI | NK19V56LS |
| NIKKEI | NK19V60 |
| NIKKEI | NK22V55 |
| NIKKEI | NK22V56FLS |
| NIKKEI | NK22V57FLS |
| NIKKEI | NK22V60 |
| NIKKEI | NK26V59 |
| NIKKEI | NK329202T |
| NIKKEI | NK32V48 |
| NIKKEI | NK32V70 |
| NIKKEI | NK32V71 |
| NODIS | ND24190CFTS |
| NODIS | ND24T2S2 |
| NODIS | ND32D11TS |
| NODIS | ND32T2S2 |
| NORMENDE | LC2022 |
| NORMENDE | LED01E32H |
| NORMENDE | LED13E22F |
| NORMENDE | LED13E24F |
| NORMENDE | LED38E40F |
| NORMENDE | LN19M1000 |
| NORMENDE | LN22M1000 |
| NORMENDE | LN32M1000 |
| NORMENDE | LSN32M1000 |
| NORMENDE | LWN32M1000 |
| NORMENDE | ND20N2000E |
| NORMENDE | ND22N2000E |
| NORMENDE | NMTX1467VE |
| NORMENDE | UN19M1000 |
| NORMENDE | UN19N1000 |
| NORMENDE | UN22M1500 |
| NORMENDE | UN22N1500 |
| NORMENDE | UN22N1504 |
| NORMENDE | UN22N2504 |
| NORMENDE | UN23N2004 |
| NORMENDE | UN24N1004 |
| NORMENDE | UN24N2004 |
| NORMENDE | UN26M1000 |
| NORMENDE | UN26N1000 |
| NORMENDE | UN32M1000 |

| | |
|-----------|---------------|
| NORDMENDE | UN32N5000 |
| NORDMENDE | UN32N1000 |
| NORDMENDE | UN32N2004 |
| NORDMENDE | UN32N5004 |
| NORDMENDE | UN39N2504 |
| NORDMENDE | UN40M5500 |
| NORDMENDE | UN40N5500 |
| NORDMENDE | UN42M1500 |
| NORDMENDE | USN22M1500 |
| OK | ODL24651HTB |
| OK | ODL32540B |
| OK | ODL32640FDIB |
| OK | ODL32641HDIB |
| OK | ODL32651HTB |
| OK | ODL32651HTW |
| OK | ODL32652FTIB |
| OK | ODL32652FTIW |
| OK | ODL32653FVTIW |
| OK | ODL39650HTB |
| OK | ODL40650UVTIB |
| OK | ODL40651FTB |
| OK | ODL43640FDIB |
| OK | ODL43650UTB |
| OK | ODL48540B1 |
| OK | ODL48650FTIB |
| OK | ODL49650UVTIB |
| OK | ODL49740UDIB |
| OK | ODL50541FDIB |
| OK | ODL55641UDIB |
| OK | ODL55651UTIB |
| OK | ODL55750UVTIB |
| OK | ODL65650UVTIB |
| OK | ODL65670UVTIB |
| OK | OLC191B04 |
| OK | OLC321B04 |
| OK | OLC321WD4 |
| OK | OLE20540B |
| OK | OLE20540HDB |
| OK | OLE22540HTB |
| OK | OLE241B04S |
| OK | OLE24540B |
| OK | OLE24540HDB |
| OK | OLE24750HVTB |
| OK | OLE24850HVTB |
| OK | OLE261B04 |
| OK | OLE321B04 |
| OK | OLE32350W |
| OK | OLE328B04 |
| OK | OLE40350TIB |
| OKI | 19VCPHTUV |
| OKI | 30063114 |
| OKI | 32JDT |
| OKI | C19VCPHTUV |
| OKI | C22VBFHDTUV |
| OKI | C26VAPHDTUV |
| OKI | C26VBPHTUV |
| OKI | C32VBFHDTUV |
| OKI | C32VBPHTUV |
| OKI | C32VCPHTUV |
| OKI | C32VDFHDTUV |
| OKI | C32VDPHTUV |
| OKI | C37VAFHTUV |
| OKI | C40VAFHTUV |
| OKI | C40VBFHDTUV |
| OKI | K26CV1H |
| OKI | L19BLED4 |
| OKI | L19VBPHTUV |
| OKI | L19VBPHTUV |
| OKI | L19VDPHTUV |
| OKI | L19VDPHTUV |
| OKI | L19VEPHTUV |
| OKI | L22VBFHDTUV |
| OKI | L22VBFHDTUV |
| OKI | L22VBPHTUV |
| OKI | L22VCFHDTUV |
| OKI | L22VCFHDTUV |
| OKI | L22VDFHDTUV |
| OKI | L22VDFHDTUV |
| OKI | L22VEFHTUV |
| OKI | L24BVFHDTUV |
| OKI | L24VBFHDTUV |
| OKI | L24VBFHDTUV |
| OKI | L24VCFHDTUV |
| OKI | L24VCFHDTUV |
| OKI | L26VBPHTUV |
| OKI | L32VBPHTUV |
| OKI | L32VDPHTUV |
| OKI | L32VEPHTUV |
| OKI | L32VFFHTUV |
| OKI | L32VGPHTUV |
| OKI | L32VHPHTUV |
| OKI | L39VAPHTUV |
| OKI | L40VDFHDTUV |

| | |
|-----------|--------------|
| OKI | L40VEFHTUV |
| OKI | L42VCFHDTUV |
| OKI | L42VDFHDTUV |
| OKI | L4IBFHTUV |
| OKI | LED22DLED |
| OKI | OKITV32TIT |
| OKI | OKITV22TD |
| OKI | OKITW22TD |
| OKI | PV15 |
| OKI | SAGA320B4USB |
| OKI | TVV37AFHU |
| OKI | TW22PHTUMI |
| OKI | TW22TD |
| OKI | TW3212 |
| OKI | TW32TD |
| OKI | V15APH |
| OKI | V16A |
| OKI | V16APHD |
| OKI | V16APHDUI |
| OKI | V19APH |
| OKI | V19BLED3 |
| OKI | V19BLED4 |
| OKI | V19BPH |
| OKI | V19BPHD |
| OKI | V19BPHDТУM |
| OKI | V19BPHDUV |
| OKI | V19BPHDUV |
| OKI | V19CPC |
| OKI | V19CPH |
| OKI | V19CPHDLUV |
| OKI | V19DPH |
| OKI | V19PPH |
| OKI | V22APH |
| OKI | V22BFH |
| OKI | V22BPHDLU |
| OKI | V22BPHDU |
| OKI | V22DHDUMI |
| OKI | V22DLED |
| OKI | V22DPH |
| OKI | V22DPHDTUMI |
| OKI | V22EDVDLED |
| OKI | V22EPHI |
| OKI | V22EPHTUMI |
| OKI | V24EDVD |
| OKI | V26AH |
| OKI | V26APHDI |
| OKI | V26APHDLU |
| OKI | V26APHDTUMI |
| OKI | V26BFHSTU |
| OKI | V26BH |
| OKI | V26BPHI |
| OKI | V26CAHTUMI |
| OKI | V26CPHTU |
| OKI | V26CPHTUMI |
| OKI | V26EPHTUMI |
| OKI | V26ELED |
| OKI | V32BH |
| OKI | V32BLED1 |
| OKI | V32BLED2 |
| OKI | V32BPHTUI |
| OKI | V32BPHTUMI |
| OKI | V32CPHTUMI |
| OKI | V32DPHTUMI |
| OKI | V32NFHTUV |
| OKI | V37AFHU |
| OKI | V37EPHTUMI |
| OKI | V40ALED1 |
| OKI | V40APHS |
| OKI | V42BFHSU |
| OKI | V42CFHTUMI |
| OKI | V42DFHSTUI |
| OKI | V42DLED |
| OKI | V46DLED |
| ONN | OLCD3701 |
| ORIMA | OR24265 |
| ORIMA | OR26906 |
| ORIMA | OR26980 |
| ORIMA | OR32281 |
| ORIMA | OR32500 |
| ORIMA | ORS40283 |
| ORION | TV19LBV100 |
| ORION | TV26LBV100 |
| ORION | TV32LBV100 |
| ORION | TV32LDV100 |
| PANASONIC | TX24CW304 |
| PANASONIC | TX32A300 |
| PANASONIC | TX32AW304 |
| PANASONIC | TX32CW304 |
| PANASONIC | TX39A300 |
| PANASONIC | TX39CW304 |
| PANASONIC | TX40CW304 |
| PANASONIC | TX43HX700E |
| PANASONIC | TX50A300 |

| | |
|------------|---------------|
| PANASONIC | TX50AW304 |
| PANASONIC | TX50HX700E |
| PANASONIC | TX55HX700E |
| PANASONIC | TX65HX700E |
| PANAVISION | 2440 |
| PHILIPS | 24HFL2802D |
| PHILIPS | RC3800 |
| POLAROID | 542LED14 |
| POLAROID | P32LED12 |
| PROLINE | 2602 |
| PROLINE | L3238HD |
| PROLINE | L4240FHD |
| PROLINE | LD1501C |
| PROLINE | LD1501G |
| PROLINE | LD1512 |
| PROLINE | LD1620D |
| PROLINE | LD1702W |
| PROLINE | LD1915D |
| PROLINE | LD1922D |
| PROLINE | LD1963D2 |
| PROLINE | LD1963D3 |
| PROLINE | LD2002 |
| PROLINE | LD2075D |
| PROLINE | LD2215D |
| PROLINE | LD2262D |
| PROLINE | LD2602 |
| PROLINE | LD2655HD |
| PROLINE | LD2656HD |
| PROLINE | LD2665D |
| PROLINE | LD3202D |
| PROLINE | LD3255HD |
| PROLINE | LD3256HD |
| PROLINE | LD3265D |
| PROLINE | LD3765 |
| PROLINE | LVD1923DX |
| PROLINE | LVD1961DX |
| PROLINE | PDP4201 |
| PVISION | FLS40THD |
| PVISION | FLW32TG |
| QILIVE | Q1008 |
| QILIVE | Q1096 |
| QILIVE | Q1209 |
| QILIVE | Q1259 |
| QILIVE | Q1324 |
| QILIVE | Q1326 |
| QILIVE | Q1475 |
| QILIVE | Q1508 |
| QILIVE | Q1527 |
| QILIVE | Q1578 |
| QILIVE | Q1638 |
| QILIVE | Q1649 |
| QILIVE | Q1722 |
| QILIVE | Q1885 |
| QILIVE | Q1892 |
| QILIVE | Q1903 |
| QILIVE | Q24985WT2 |
| QILIVE | Q32161 |
| QILIVE | Q32164 |
| QILIVE | Q32822 |
| QILIVE | Q32823 |
| QILIVE | Q43372 |
| QILIVE | Q55181 |
| QUADRO | LCD32AB15(V2) |
| QUADRO | LED24DN41 |
| QUADRO | LED24DN51 |
| QUADRO | LED24DN52 |
| QUADRO | LED24GL40 |
| QUADRO | LED26DN42 |
| QUADRO | LED32BN40 |
| QUADRO | LED32BN41 |
| QUADRO | LED32DN41 |
| QUADRO | LED32DN52 |
| QUADRO | LED32DN82 |
| QUADRO | LED32HN40 |
| QUADRO | LED32HN41 |
| QUADRO | LED32SN41 |
| QUADRO | LED32TN41 |
| QUADRO | LED32XM41 |
| QUADRO | LED32XM41 |
| QUADRO | TFT20DT1TIP2 |
| QUADRO | WP10 |
| QUADRO | WP15 |
| RENDER | LCD1507 |
| ROADSTAR | 1439TS |
| ROADSTAR | CTV1439 |
| ROADSTAR | CTV1439T/S |
| ROADSTAR | CTV2039T/S |
| ROADSTAR | CTV2139 |
| ROADSTAR | CTV2139T/S |
| ROADSTAR | SF091 |
| SABA | 22FHDLEDE16 |
| SABA | 24FHDLEDE16 |
| SABA | 32HDOLEDED3 |

| | |
|--------|---------------|
| SABA | KL32B100 |
| SABA | KLW32B100 |
| SABA | KU22A100 |
| SABA | KU22A200 |
| SABA | L191JC |
| SABA | L221JC |
| SABA | L2611JC(v2) |
| SABA | L26A100 |
| SABA | L321JC |
| SABA | L37B150 |
| SABA | L40PV882 |
| SABA | L421JC |
| SABA | LD22DV137 |
| SABA | LD22DV164 |
| SABA | LD32V167 |
| SABA | LD32VS249 |
| SABA | LE19PV905 |
| SABA | LE19PV905/135 |
| SABA | LE20PV114 |
| SABA | LE22DVDWH |
| SABA | LE22PV905 |
| SABA | LE24PV13 |
| SABA | LE26PV916 |
| SABA | LE28PV114 |
| SABA | LE32PV03 |
| SABA | LE32PV0313 |
| SABA | LE32PV114 |
| SABA | LE32PV11WH |
| SABA | LE32PV15B |
| SABA | LE32PV16 |
| SABA | LE32PV17 |
| SABA | LE32PV412 |
| SABA | LE32PV905WH |
| SABA | LE40PV16 |
| SABA | LE40PV512 |
| SABA | LE43PV18 |
| SABA | LE46PV512 |
| SABA | LE48PV16 |
| SABA | LE49PV17 |
| SABA | LE50PV114 |
| SABA | LE50PV115 |
| SABA | LE55PV15 |
| SABA | LE55PV17 |
| SABA | LE65PV15 |
| SABA | LE65PV17 |
| SABA | LED1600JC |
| SABA | LED1900JC |
| SABA | LED2200JC |
| SABA | LED3200JC |
| SABA | LED3211JC |
| SABA | LED4000JC |
| SABA | LED4200JC |
| SABA | LED4600JC |
| SABA | LED5500JC |
| SABA | LF221JC |
| SABA | LF261JC |
| SABA | LF3200JC |
| SABA | LF321JC(v2) |
| SABA | LW26A200 |
| SABA | LW32B200 |
| SABA | S19905LED |
| SABA | S22104LED |
| SABA | S231JC |
| SABA | S26104 |
| SABA | S26VT08 |
| SABA | S32683 |
| SABA | S32905LED |
| SABA | S32VT08 |
| SABA | S42905DLED |
| SABA | SB43UHD18 |
| SABA | SB43UHD19 |
| SABA | SB49UHD18 |
| SABA | SB55UHD18 |
| SABA | SB65UHD18WEB |
| SABA | SB75UHD18WEB |
| SABA | SV49UHD17BS |
| SABA | SV55UHD18BS |
| SABA | SV55UHD18S |
| SABA | U19A200 |
| SABA | U22A200 |
| SABA | U22A250 |
| SABA | U26A100 |
| SABA | U32A200 |
| SABA | U32A200NET |
| SABA | U32B100 |
| SABA | U32B200 |
| SABA | U32B3D |
| SABA | U40B3D |
| SABA | U42A100 |
| SABA | U42B3D |
| SABA | UW22A200 |
| SABA | UW22A250 |
| SAIVOD | LED2414FHDGR |

SAIVOD LED3214FHDGR
 SAIVOD TFT204CI
 SALORA 19LED9000BK
 SALORA 32LED7100C
 SALORA 32LED7105CD
 SALORA 32LED7115CDW
 SALORA LCD1931DVX
 SANITRON 22SF10
 SANSUI 14TX1446SLV
 SANSUI 20TX
 SANSUI 21TX2146SLV
 SANYO CE20L01
 SANYO CE37HW03
 SCHNEIDER 20TXBIF
 SCHNEIDER 21TXBIF
 SCHNEIDER CHRO-
 MIA24DZEL
 SCHNEIDER CHRO-
 MIA3915FHD
 SCHNEIDER EXIA1601PVR
 SCHNEIDER EXIA1901PVR
 SCHNEIDER EXIA1905PVR
 SCHNEIDER EXIA2205PVR
 SCHNEIDER EXIA3120FHD
 SCHNEIDER EXIA4214FHD
 SCHNEIDER EXIAHD1910USB
 SCHNEIDER EXIAHD2210USB
 SCHNEIDER EXIAHD2610USB
 SCHNEIDER EXIAHD2611MKV
 SCHNEIDER EXIAHD2614
 SCHNEIDER EXIAHD3211USB
 SCHNEIDER EXIAHD3214
 SCHNEIDER EXIAHD4214
 SCHNEIDER KAZA3220SMART
 SCHNEIDER LD285CA65H
 SCHNEIDER LD323CN06HB
 SCHNEIDER LD395C18HB
 SCHNEIDER LD395CE19HB
 SCHNEIDER LED246272CS
 SCHNEIDER LED246772CS
 SCHNEIDER LED326072CS
 SCHNEIDER LED326272CS
 SCHNEIDER LED397272CS
 SCHNEIDER LENA3202USB
 SCHNEIDER MICRA2225FHD
 SCHNEIDER MICRA3225USB
 SCHNEIDER MOONLIT1925USB
 SCHNEIDER MOONLIT202FHD
 SCHNEIDER NINZA2602PVR
 SCHNEIDER NINZA3202PVR
 SCHNEIDER NUVIA4228
 SCHNEIDER OLYA3203PVR
 SCHNEIDER 3920SMARTFHD
 SCHNEIDER SETELIA2650USB
 SCHNEIDER SHADOW1241
 SCHNEIDER STELIAHD2614
 SCHNEIDER STV3683
 SCHNEIDER VESTA2229FHD
 SCHNEIDER VESTA2422FHD
 SCHNEIDER VEXA1931USB
 SCHNEIDER VEXA2231FHD
 SCHNEIDER VIVA1910HD
 SCHNEIDER VIVA4020FHD
 SCHNEIDER VOLKA4009FHD
 SCHNEIDER ZAPPA3259SMARTHD
 SCHNEIDER ZENDA1919USB
 SCHNEIDER ZITTI1900HD
 SEEVUE 472614V2
 SEG ALASKA
 SEG CARIBIC
 SEG CARIBICII-LCD
 SEG CHASSIS11AK56
 SEG CORTINAS
 SEG CT73681
 SEG DUBLINIIS
 SEG DUBLINS
 SEG GLASGOWM
 SEG GLASGOWS
 SEG KOBE
 SEG KYOTO
 SEG LCDTV2605
 SEG LCDTV2700
 SEG LCDTV3000
 SEG LCDTV5100
 SEG LCDTV514200
 SEG LCDTV515200
 SEG LCDTV516201
 SEG LCDTV5325
 SEG LCDTV5326
 SEG LCDTV62625
 SEG LCDTV668270
 SEG LCDTV765300
 SEG MANISA

SEG MERANOSII
 SEG MYTOS
 SEG NAGANO
 SEG PACIFIC
 SEG PACIFIC(V2)
 SEG PALERMOIIS
 SEG PALERMOS
 SEG PL42SG
 SEG SANMARINOS
 SEG SIENAS
 SEG TORNADO
 SEG VALENCIA
 SEG TOKYO SAM42V2
 SEG TOKYO SAM42V3
 SELECLINE 19182I
 SELECLINE 20265I
 SELECLINE 20265T2
 SELECLINE 22182
 SELECLINE 22284
 SELECLINE 32182
 SELECLINE 32284T2
 SELECLINE 32285I
 SELECLINE 32S17T2
 SELECLINE 32S18T2
 SELECLINE 39182I
 SELECLINE 39716
 SELECLINE 40284I
 SELECLINE 40284T2
 SELECLINE 874252LE24190T2
 SELECLINE 883860LE20190T2
 SELECLINE 886919LE2219D
 SELECLINE 894526/24S17T2
 SELECLINE LE2219D
 SELECO SE32HDT(V2)
 SHARP LC19LE510E
 SHARP LC22D12E
 SHARP LC22DV240EX
 SHARP LC22DV510E
 SHARP LC22LE240
 SHARP LC22LE510E
 SHARP LC22LS240E
 SHARP LC22LS240EX
 SHARP LC24LE240
 SHARP LC24LE510E
 SHARP LC24LS240E
 SHARP LC24LS240EX
 SHARP LC32LD135E(V2)
 SHARP LC32LD145E
 SHARP LC32LE140E
 SHARP LC32LE240
 SHARP LC32LE343E
 SHARP LC32LE510E
 SHARP LC32LE530E
 SHARP LC32SH130E
 SHARP LC32SH340E
 SHARP LC39LD135E
 SHARP LC39LD145E
 SHARP LC40LE240
 SHARP LC40LE343E
 SHARP LC40LE510E
 SHARP LC40LE530E
 SHARP LC40SH340E
 SHARP LC42LE756(V2)
 SHARP LC42LE758(V2)
 SHARP LC42LE759(V2)
 SHARP LC42LE761(V2)
 SHARP LC42LE762(V2)
 SHARP LC42LE771E
 SHARP LC50LE756(V2)
 SHARP LC50LE758(V2)
 SHARP LC50LE759(V2)
 SHARP LC50LE761(V2)
 SHARP LC50LE762(V2)
 SHARP LC50LE771E
 SILVERCREST CT1407
 SILVERCREST CT1408
 SILVERCREST LCDTV32104
 SILVERCREST LEDTV22104
 SINUDYNE SYU19KV100
 SINUDYNE SYU22KV150
 SINUDYNE SYU23KV251
 SINUDYNE SYU32KV100
 SINUDYNE SYU32KV220
 SMARTTECH LE1919
 SMARTTECH LE2019DTS
 SMARTTECH LE2025TS
 SMARTTECH LE2219
 SMARTTECH LE2419DTS
 SMARTTECH LE2421TS
 SMARTTECH LE2822
 SMARTTECH LE3222TS
 SMARTTECH LE32211TS
 SMARTTECH LE32D7

SMARTTECH LE32D71S
 SMARTTECH LE32P18SA10
 SMARTTECH LE32Z3T2
 SMARTTECH LE3918
 SMARTTECH LE4018TS
 SMARTTECH LE4019NTS
 SMARTTECH LE4318TS
 SMARTTECH LE5018
 SMARTTECH LE5519TS
 SMARTTECH LE6519
 SMARTTECH SMT24N30HC1L1B1
 SMARTTECH SMT24Z30HC1L1B1
 SMARTTECH SMT3217
 SMARTTECH SMT32N30HC1L1B1
 SMARTTECH SMT32Z10HC1L1B1
 SMARTTECH SMT32Z1TS
 SMARTTECH SMT32Z30HC1L1B1
 SMARTTECH SMT32Z4TS
 SMARTTECH SMT39Z30HC1L1B1
 SMARTTECH SMT40Z30FC1L1B1
 SMARTTECH SMT43Z30FC1L1B1
 SONOKO SK32D11
 SONOKO SNKLE2419DTS
 SONOKO SNKLE24Z1TS
 SONOKO SNKLE2819TS
 SONOKO SNKLE32D11TS
 SONOKO SNKLE32Z1TS
 SONOKO SNKLE4219HTS
 SONOKO SNKLE5018NTS
 SONOKO SNKLE556UDS
 STREAMSYSTEM BM2419
 STRONG SRTL2250
 STRONG SRTL2350
 STRONG SRTL2750
 STRONG SRTL3050
 STRONG SRTL3250
 STRONG SRTL4250
 SUNSTECH 19LEDTIRSA BK
 SUNSTECH 20LEDTIRSA
 SUNSTECH 20SUN19D
 SUNSTECH 22LED CLOUD
 SUNSTECH 22LED CLOUDWT
 SUNSTECH 22LED TALUS
 SUNSTECH 24LED CLOUD
 SUNSTECH 24LED CLOUDWT
 SUNSTECH 24LED EXO BK
 SUNSTECH 24LED TIRSA BK
 SUNSTECH 24SUNDT519
 SUNSTECH 263DTIRSA BK
 SUNSTECH 28LED CLON BK
 SUNSTECH 28LED TANDA
 SUNSTECH 28LED TIRSA BK
 SUNSTECH 32DLED8TIRSA BK
 SUNSTECH 32DLED CLOUD BK
 SUNSTECH 32SMARTIRSA BK
 SUNSTECH 32SUN11TS
 SUNSTECH 32SUNDT522
 SUNSTECH 32SUNZ1TS
 SUNSTECH 39SMARTIRSA BK
 SUNSTECH 39SUN18TS
 SUNSTECH 40DLED CLOUD
 SUNSTECH 40SUN19TS
 SUNSTECH 42SUN19TS
 SUNSTECH 50SUN19TS
 SUNSTECH TLE119HDMKII
 SUNSTECH TLE122HDMKII
 TDSYSTEMS 22FHD1
 TDSYSTEMS K20LV1H
 TDSYSTEMS K22LV1F
 TDSYSTEMS K23LV1H
 TDSYSTEMS K24DLT7F
 TDSYSTEMS K24LV1H
 TDSYSTEMS K24LV2H
 TDSYSTEMS K24LV3H
 TDSYSTEMS K24SMH1
 TDSYSTEMS K32DLV1H
 TDSYSTEMS K32DLV3H
 TDSYSTEMS K32LV1H
 TDSYSTEMS K32LV1HSM
 TDSYSTEMS K40DLV1F
 TDSYSTEMS K40DLV1FSM
 TDSYSTEMS K40DLV2F
 TDSYSTEMS K40DLV3F(V2)
 TDSYSTEMS K48DLV3F
 TDSYSTEMS K50DLV1F
 TDSYSTEMS L19VEPHTUV
 TDSYSTEMS L22VEPHTUV
 TEAC/TEAK 20142179
 TEAC/TEAK EU2816STF
 TEAC/TEAK EU2845ST
 TEAC/TEAK EU3216STF
 TEAC/TEAK EU3242ST
 TEAC/TEAK EU6650ST

TEAC/TEAK EU7650S1
 TEAC/TEAK LCD221
 TECHLINE CTV481687V/TLCD
 TECHLINE CTV481787V/TLCD
 TECHLINE CTV481887V/TLCD
 TECHLINE CTV482887V/PLA
 TECHLINE LCDTV385150
 TECHLINE LCDTV514200
 TECHLINE LCDTV515200
 TECHLINE LCDTV665260
 TECHLINE LCDTV668270
 TECHLINE LCDTV765300
 TECHLINE TL20LC09
 TECHLINE TL20LC11
 TECHLINE TL20LC12
 TECHLINE TL20LC14
 TECHLINE TL20LC15
 TECHLINE TL20LC16
 TECHLINE TL20LC700
 TECHLINE TL20LC707
 TECHLINE TL30LC08
 TECHLINE TL30LC09
 TECHLINE TL32LC08
 TECHLINE TL32LC16
 TECHLINE TL32LC700
 TECHLINE TL37LC11
 TECHWOOD LCD2607HD
 TECHWOOD LCD3207HD
 TECHWOOD PH103S
 TECHWOOD PL42SI
 TECHWOOD T32DLSM8TFX15PC
 TECHWOOD TC1912TN862
 TECHWOOD TC19132LED
 TECHWOOD TC19134LED
 TECHWOOD TC20227LED16
 TECHWOOD TC2209TN875
 TECHWOOD TC2212TN862
 TECHWOOD TC26751LS
 TECHWOOD TC3211HD906
 TECHWOOD TC32122DLED2
 TECHWOOD TC321898M8LED
 TECHWOOD TC32751LS
 TECHWOOD TC32930DLED
 TECHWOOD TC40127DLED
 TECHWOOD TC49278DLED
 TECHWOOD TK1505LCD
 TECHWOOD TW19820N15
 TECHWOOD TW22911B19
 TECHWOOD TW22916B19LED
 TECHWOOD TW24916B19
 TECHWOOD TW26860B19
 TECHWOOD TW26916B19
 TECHWOOD TW32970N17
 TECHWOOD TW43296S24T1P
 TECHWOOD VLED19TV1201
 TECHWOOD VLED22TVHD1201
 TECHWOOD VLED26TV1101
 TELEFUNKEN CF32H130KCT82B
 TELEFUNKEN D32F287N3CW
 TELEFUNKEN D32H125A3C
 TELEFUNKEN D32H125N3
 TELEFUNKEN D32H27813
 TELEFUNKEN D32H280Q3
 TELEFUNKEN D32H287A3
 TELEFUNKEN D32H289N3C
 TELEFUNKEN D39F275N3C
 TELEFUNKEN D40F182C3C
 TELEFUNKEN D40F275A3C
 TELEFUNKEN D42F275
 TELEFUNKEN D43F278N3CW
 TELEFUNKEN D43F287N4CW
 TELEFUNKEN D48F275
 TELEFUNKEN D49F279N3CW
 TELEFUNKEN D49F283
 TELEFUNKEN D50F273
 TELEFUNKEN D55F287N3CW
 TELEFUNKEN D55U300N4CW
 TELEFUNKEN EXPTE395827YXH
 TELEFUNKEN EXPTE43835ZK
 TELEFUNKEN EXPTE43835ZK5AT
 TELEFUNKEN EXPTE49831Y2P
 TELEFUNKEN L24H275K3
 TELEFUNKEN L24H472R4
 TELEFUNKEN SOMNIA22ESM
 TELEFUNKEN SOMNIA24ESM
 TELEFUNKEN SOMNIA24ESTV
 TELEFUNKEN SOMNIA27ESM
 TELEFUNKEN SOMNIA32DES
 TELEFUNKEN SOMNIA32DWE
 TELEFUNKEN T24TX168LBP
 TELEFUNKEN T32CT906FHD
 TELEFUNKEN T32FHD845CT
 TELEFUNKEN T32FX189LBP
 TELEFUNKEN T32R847DV6T

TELEFUNKEN T327X182DLBP
TELEFUNKEN T327X189DLBP
TELEFUNKEN T327X189LBP
TELEFUNKEN T327X275DLBP
TELEFUNKEN T327X282DLBP
TELEFUNKEN T327X287DLBP(V2)
TELEFUNKEN T37R894FHD
TELEFUNKEN T37R912
TELEFUNKEN T39FX275DLBP
TELEFUNKEN T40FX182DLP
TELEFUNKEN T40FX275DLBP
TELEFUNKEN T42FX275DLBP
TELEFUNKEN T43FX280DLBP
TELEFUNKEN T43FX280DLBP
TELEFUNKEN T46R892FHD
TELEFUNKEN T50FV273DLBP
TELEFUNKEN T50FV275DLBP
TELEFUNKEN T815D783
TELEFUNKEN TE14440T
TELEFUNKEN TE1579685
TELEFUNKEN TE159485
TELEFUNKEN TE16857MN15
TELEFUNKEN TE16857TD9N
TELEFUNKEN TE16857X
TELEFUNKEN TE16857XND
TELEFUNKEN TE16910MD817
TELEFUNKEN TE16912817
TELEFUNKEN TE19135819
TELEFUNKEN TE19180830C10
TELEFUNKEN TE19180831T10
TELEFUNKEN TE19180820T10E
TELEFUNKEN TE1918281910ELED
TELEFUNKEN TE19822811
TELEFUNKEN TE19857
TELEFUNKEN TE19857MB5
TELEFUNKEN TE19857TD9N
TELEFUNKEN TE19857XN4
TELEFUNKEN TE19880811
TELEFUNKEN TE19880817
TELEFUNKEN TE19880819
TELEFUNKEN TE1988085
TELEFUNKEN TE1988089
TELEFUNKEN TE19880N15
TELEFUNKEN TE19880XN4
TELEFUNKEN TE1988811
TELEFUNKEN TE19910817LED
TELEFUNKEN TE19910819
TELEFUNKEN TE19915817H
TELEFUNKEN TE19915819
TELEFUNKEN TE19919817
TELEFUNKEN TE19970819
TELEFUNKEN TE19975819
TELEFUNKEN TE19980819
TELEFUNKEN TE20265830C10
TELEFUNKEN TE20265820T10E
TELEFUNKEN TE20270830CXBW
TELEFUNKEN TE20278835
TELEFUNKEN TE20880811
TELEFUNKEN TE20EUB35TXB
TELEFUNKEN TE22137819
TELEFUNKEN TE22180829C10
TELEFUNKEN TE22180829FC10
TELEFUNKEN TE22182829C10
TELEFUNKEN TE22182829FC10E
TELEFUNKEN TE22182830FC10E
TELEFUNKEN TE22182820FT10E
TELEFUNKEN TE22275830CXG
TELEFUNKEN TE22275830FC10E
TELEFUNKEN TE22275831FT10E
TELEFUNKEN TE22275835TXG
TELEFUNKEN TE22275835ZTXG
TELEFUNKEN TE22283F30C10E
TELEFUNKEN TE222857DN9
TELEFUNKEN TE222880DN9
TELEFUNKEN TE222882DN9
TELEFUNKEN TE22472840Q2B
TELEFUNKEN TE22472840Y2B
TELEFUNKEN TE22472827TXG
TELEFUNKEN TE22472827YXG
TELEFUNKEN TE22472827YXG/W
TELEFUNKEN TE22472827ZXG
TELEFUNKEN TE22502827YXG
TELEFUNKEN TE22502827YXG/W
TELEFUNKEN TE22857811
TELEFUNKEN TE22857M
TELEFUNKEN TE22857XN4
TELEFUNKEN TE22880811
TELEFUNKEN TE22880898
TELEFUNKEN TE22880N15
TELEFUNKEN TE22880XN4
TELEFUNKEN TE2288285
TELEFUNKEN TE22882XN4
TELEFUNKEN TE2288585
TELEFUNKEN TE22910817
TELEFUNKEN TE22910819
TELEFUNKEN TE22911817
TELEFUNKEN TE22914819
TELEFUNKEN TE22915817FH
TELEFUNKEN TE22915819
TELEFUNKEN TE22970819F

TELEFUNKEN TE22975819F
TELEFUNKEN TE22980819F
TELEFUNKEN TE22983819E
TELEFUNKEN TE22EUB35TXG
TELEFUNKEN TE22WHB35TXG
TELEFUNKEN TE23265830C10
TELEFUNKEN TE23265820T10E
TELEFUNKEN TE23911817F
TELEFUNKEN TE23911819
TELEFUNKEN TE23914819
TELEFUNKEN TE23914829
TELEFUNKEN TE24114830
TELEFUNKEN TE24125829FC10
TELEFUNKEN TE24180829C10
TELEFUNKEN TE24180830C10
TELEFUNKEN TE24180831T10
TELEFUNKEN TE24182829C10ELED
TELEFUNKEN TE24265830C10E
TELEFUNKEN TE24275830C10
TELEFUNKEN TE24275830CXB
TELEFUNKEN TE24275831T10E
TELEFUNKEN TE24275835TXB
TELEFUNKEN TE24282830C10
TELEFUNKEN TE24282835TXB
TELEFUNKEN TE24282835TXBW
TELEFUNKEN TE24282835ZXB
TELEFUNKEN TE24282838Y2B
TELEFUNKEN TE24282827TXB
TELEFUNKEN TE24282827ZXB
TELEFUNKEN TE24282830C10E
TELEFUNKEN TE24283840Q2A
TELEFUNKEN TE24283827YXA
TELEFUNKEN TE2428382T2
TELEFUNKEN TE2447252JXF
TELEFUNKEN TE24472837TXB
TELEFUNKEN TE24472840Q2B
TELEFUNKEN TE24472840Y2B
TELEFUNKEN TE24472840Y2BW
TELEFUNKEN TE24472840Y2F
TELEFUNKEN TE24472827YXAW
TELEFUNKEN TE24472827YXB
TELEFUNKEN TE24472827YXBW
TELEFUNKEN TE24472827YXF
TELEFUNKEN TE24472827YXFW
TELEFUNKEN TE24475827YXB
TELEFUNKEN TE24550840Q2D
TELEFUNKEN TE24550842V2D
TELEFUNKEN TE24550827YXD
TELEFUNKEN TE24880817FH
TELEFUNKEN TE24916817
TELEFUNKEN TE24916819F
TELEFUNKEN TE24D0V827TXB
TELEFUNKEN TE24EUB35TXB
TELEFUNKEN TE24EUB37TXB
TELEFUNKEN TE24MDV0827TXB
TELEFUNKEN TE26137819
TELEFUNKEN TE2685781
TELEFUNKEN TE26857PS1
TELEFUNKEN TE26860819
TELEFUNKEN TE26880817
TELEFUNKEN TE26880819
TELEFUNKEN TE26880N13F
TELEFUNKEN TE26916819H
TELEFUNKEN TE26975819H
TELEFUNKEN TE28180829C10
TELEFUNKEN TE28227829C10E
TELEFUNKEN TE28272830C10
TELEFUNKEN TE28272827TXBW
TELEFUNKEN TE28272827YXAW
TELEFUNKEN TE28272827YXBW
TELEFUNKEN TE28275830C10
TELEFUNKEN TE28275831E
TELEFUNKEN TE28275831T10E
TELEFUNKEN TE28275835TXB
TELEFUNKEN TE28275835ZXB
TELEFUNKEN TE28275840Q2B
TELEFUNKEN TE28275840Y2A
TELEFUNKEN TE28275827TXG
TELEFUNKEN TE28275827YXA
TELEFUNKEN TE28275827YXB
TELEFUNKEN TE28275827ZXB
TELEFUNKEN TE28277829C10E
TELEFUNKEN TE288MB35Z2B
TELEFUNKEN TE28WHB35Z2B
TELEFUNKEN TE32114N22C10U
TELEFUNKEN TE32125830C10
TELEFUNKEN TE32130817H
TELEFUNKEN TE32130816C10
TELEFUNKEN TE32160829C10
TELEFUNKEN TE32160830C10D
TELEFUNKEN TE32180829C10
TELEFUNKEN TE32180830C10
TELEFUNKEN TE32180816C10
TELEFUNKEN TE32182829C10
TELEFUNKEN TE32182830C10
TELEFUNKEN TE32182831T10
TELEFUNKEN TE322408
TELEFUNKEN TE32240820C15
TELEFUNKEN TE32265830C10D
TELEFUNKEN TE32265838Y2D

TELEFUNKEN TE32269838Y2H
TELEFUNKEN TE32269840Q2D
TELEFUNKEN TE32269840Q2D/W
TELEFUNKEN TE32269840Y2D
TELEFUNKEN TE32269840Y2D/W
TELEFUNKEN TE32269840Y2H
TELEFUNKEN TE32269827YXW
TELEFUNKEN TE32269827YXW/D
TELEFUNKEN TE32274835TXD/W
TELEFUNKEN TE32275830C10
TELEFUNKEN TE32275831T10D
TELEFUNKEN TE32275820T10D
TELEFUNKEN TE32278830C10D
TELEFUNKEN TE32278835
TELEFUNKEN TE32280831T10D
TELEFUNKEN TE32282830C10D
TELEFUNKEN TE32282830C10
TELEFUNKEN TE32283830C10D
TELEFUNKEN TE32287830C10
TELEFUNKEN TE32287835T2D
TELEFUNKEN TE32287835T2D
TELEFUNKEN TE32287835TXD
TELEFUNKEN TE32287835ZXD
TELEFUNKEN TE32470827TXD/W
TELEFUNKEN TE32472827TXD
TELEFUNKEN TE32472827YXD
TELEFUNKEN TE32472827ZXD
TELEFUNKEN TE32487FB1
TELEFUNKEN TE324EUB27
TELEFUNKEN TE32550840Q2D
TELEFUNKEN TE32550840Q2D/W
TELEFUNKEN TE32550842V2D
TELEFUNKEN TE32550842V2H
TELEFUNKEN TE32550845V2D
TELEFUNKEN TE32550827YXD
TELEFUNKEN TE32550827YXD/W
TELEFUNKEN TE32550838YXD
TELEFUNKEN TE32551840Q2D
TELEFUNKEN TE32552840Q2H
TELEFUNKEN TE32552838YXD
TELEFUNKEN TE32554054Q2DA
TELEFUNKEN TE32554054Q2HA
TELEFUNKEN TE32761B1
TELEFUNKEN TE32843816FH
TELEFUNKEN TE32843N13
TELEFUNKEN TE32845817
TELEFUNKEN TE32847FB1
TELEFUNKEN TE32857
TELEFUNKEN TE32860819
TELEFUNKEN TE32860N17
TELEFUNKEN TE32880817
TELEFUNKEN TE32880N13
TELEFUNKEN TE32882816FH
TELEFUNKEN TE32882N13
TELEFUNKEN TE32883N17
TELEFUNKEN TE32900816H
TELEFUNKEN TE32905
TELEFUNKEN TE32905816HLED
TELEFUNKEN TE32905N17HLED
TELEFUNKEN TE32910817FH
TELEFUNKEN TE32910N16
TELEFUNKEN TE32914829C10
TELEFUNKEN TE32914N17H
TELEFUNKEN TE32915816H
TELEFUNKEN TE32915817FH
TELEFUNKEN TE32915N17H
TELEFUNKEN TE32917N17
TELEFUNKEN TE32931N17H
TELEFUNKEN TE32931N17HD
TELEFUNKEN TE32931N17HLED
TELEFUNKEN TE32975N16H
TELEFUNKEN TE32975N17
TELEFUNKEN TE32980N17H
TELEFUNKEN TE32EUB35TXD
TELEFUNKEN TE32EUB35TXD
TELEFUNKEN TE32FHS27TXH
TELEFUNKEN TE32FHS27TXH
TELEFUNKEN TE32HD857L
TELEFUNKEN TE328MB35Z2D
TELEFUNKEN TE328MB35Z2D
TELEFUNKEN TE32WHB35Z2D
TELEFUNKEN TE39180829C10
TELEFUNKEN TE39180N22FC10
TELEFUNKEN TE39182829C10
TELEFUNKEN TE39182N22
TELEFUNKEN TE39182N25
TELEFUNKEN TE39182N25FC10
TELEFUNKEN TE39227N22FC10D
TELEFUNKEN TE39275835T2H
TELEFUNKEN TE39275835TXH
TELEFUNKEN TE39275N25CXH
TELEFUNKEN TE39275N25FC10D
TELEFUNKEN TE39472838Y2D
TELEFUNKEN TE39472840Q2H
TELEFUNKEN TE39472840Y2D
TELEFUNKEN TE39472825TXD
TELEFUNKEN TE39472827TXD
TELEFUNKEN TE39472827YXD
TELEFUNKEN TE39472827YXD
TELEFUNKEN TE39472827ZXD

TELEFUNKEN TE39FND840Q2D
TELEFUNKEN TE39FND842V2D
TELEFUNKEN TE39FND827YXD
TELEFUNKEN TE398MB35Z2D
TELEFUNKEN TE39WHB35Z2D
TELEFUNKEN TE40127N22FC10
TELEFUNKEN TE40182N22FC10
TELEFUNKEN TE40182N25FC10D
TELEFUNKEN TE40282834C2H
TELEFUNKEN TE40282820FC10E
TELEFUNKEN TE40272N25FC10D
TELEFUNKEN TE40275N28FT10D
TELEFUNKEN TE40280N28FT10D
TELEFUNKEN TE40282834C2H
TELEFUNKEN TE40282838Y2K
TELEFUNKEN TE40282840Q2K
TELEFUNKEN TE40282840Y2H
TELEFUNKEN TE40282840Y2K
TELEFUNKEN TE40282825FC10D
TELEFUNKEN TE40282825T2H
TELEFUNKEN TE40282825TXH
TELEFUNKEN TE40282827YXK
TELEFUNKEN TE40283N25FC10D
TELEFUNKEN TE40287840Q2J
TELEFUNKEN TE40292831Y2P
TELEFUNKEN TE40301G37T2P
TELEFUNKEN TE407817FHD
TELEFUNKEN TE40820F82
TELEFUNKEN TE4088282
TELEFUNKEN TE40910N16F
TELEFUNKEN TE40970818FH
TELEFUNKEN TE40970N17F
TELEFUNKEN TE42182N25FC10D
TELEFUNKEN TE42340Q28FT10
TELEFUNKEN TE42820F82
TELEFUNKEN TE4285781
TELEFUNKEN TE42880819FHD
TELEFUNKEN TE42880819HLED
TELEFUNKEN TE42882816FH
TELEFUNKEN TE42910
TELEFUNKEN TE42914816FH
TELEFUNKEN TE42930818FH
TELEFUNKEN TE43268831Q2P
TELEFUNKEN TE43268831Q2P/W
TELEFUNKEN TE43282834C2K
TELEFUNKEN TE43282835Z2K
TELEFUNKEN TE43282840Q2K
TELEFUNKEN TE43282825CXK
TELEFUNKEN TE43282825T2K
TELEFUNKEN TE43282825TXK
TELEFUNKEN TE43282825ZXX
TELEFUNKEN TE43292G37Z2P
TELEFUNKEN TE43292831
TELEFUNKEN TE43292831Q2P
TELEFUNKEN TE43292831Y2P
TELEFUNKEN TE43301G37T2R
TELEFUNKEN TE43301G37Z2R
TELEFUNKEN TE43404G37Z2P
TELEFUNKEN TE43406G37T2P
TELEFUNKEN TE43472840Q2K
TELEFUNKEN TE43472829Y2K
TELEFUNKEN TE43472833Y2K
TELEFUNKEN TE4350840Q2K
TELEFUNKEN TE4350827YXH
TELEFUNKEN TE4350839Y2P
TELEFUNKEN TE4350839V2P
TELEFUNKEN TE43551840Q2K
TELEFUNKEN TE43551842V2K
TELEFUNKEN TE43554G54V2KA
TELEFUNKEN TE438352K/SAT
TELEFUNKEN TE438MB35Z2K
TELEFUNKEN TE48275820FT10
TELEFUNKEN TE48275820FT10D
TELEFUNKEN TE48282825T2K
TELEFUNKEN TE48282825TXK
TELEFUNKEN TE48282829Y2K
TELEFUNKEN TE48282833X2K
TELEFUNKEN TE48282833Y2K
TELEFUNKEN TE48301G37T2R
TELEFUNKEN TE488MB35Z2K
TELEFUNKEN TE49269826Y2P
TELEFUNKEN TE49280N25FCXK
TELEFUNKEN TE49280N28FT10D
TELEFUNKEN TE49280820F2
TELEFUNKEN TE49282834C2H
TELEFUNKEN TE49282825T2K
TELEFUNKEN TE49282825TXK
TELEFUNKEN TE49283N25FC10D
TELEFUNKEN TE49287840Q2K
TELEFUNKEN TE49292G37T2P
TELEFUNKEN TE49292826Y2P
TELEFUNKEN TE49292831Q2P
TELEFUNKEN TE49292831Y2P
TELEFUNKEN TE49306G37T2R
TELEFUNKEN TE49405831Q2R
TELEFUNKEN TE4940H824Z2P
TELEFUNKEN TE50273820FC10
TELEFUNKEN TE50275N25
TELEFUNKEN TE50282834
TELEFUNKEN TE50282835Z2K

TELEFUNKEN TE5028282512K
 TELEFUNKEN TE50282825TXK
 TELEFUNKEN TE502828252XX
 TELEFUNKEN TE50282833Y2K
 TELEFUNKEN TE50292826Y2P
 TELEFUNKEN TE50292831Q2P
 TELEFUNKEN TE50292831V2P
 TELEFUNKEN TE50550839V2P
 TELEFUNKEN TE55287825T2M
 TELEFUNKEN TE55292837T2P
 TELEFUNKEN TE55292837Z2P
 TELEFUNKEN TE55292826Y2P
 TELEFUNKEN TE55301G37T2R
 TELEFUNKEN TE55EU8252ZM
 TELEFUNKEN TE55UH824Z2P
 TELEFUNKEN TE58550831Q2P
 TELEFUNKEN TE65240326F4C10
 TELEFUNKEN TE65240377T2R
 TELEFUNKEN TE65404G37T2P
 TELEFUNKEN TE65404S26Y2P
 TELEFUNKEN TE65404S31Q2P
 TELEFUNKEN TFL425070B
 TELEFUNKEN TLFK42F3D12
 TELEFUNKEN T82807612
 TELEFUNKEN T8320761L5
 TELEFUNKEN T8320875L5
 TELEFUNKEN T8320875L5(V2)
 TELEFUNKEN TX32550827YXH
 TELEFUNKEN XU55G529
 TELESYSTEM PALCO16L02
 TELESYSTEM PALCO16L02COMBO
 TELESYSTEM PALCO19L02
 TELESYSTEM PALCO19L02COMBO
 TELESYSTEM PALCO22L02
 TELESYSTEM PALCO22L02COMBO
 TELESYSTEM PALCO26L02COMBO
 TELESYSTEM PALCO32L02
 TEVION MD30302
 THOMSON B1604LVDX
 THOMSON B1605LVDX
 THOMSON B1903LVDX
 THOMSON B1905LVDX
 THOMSON B1907LVDX
 THOMSON B2205LVDX
 THOMSON B2207
 THOMSON B2207LD
 THOMSON B2207XHDW
 THOMSON B2213HD2
 THOMSON B2420HD
 THOMSON B3207LD
 THOMSON B3216HD
 TOKAI LTV2155R
 TOKAI TTE24H1204WK
 TOKAI TTE24H814AK
 TOKAI TTE32K2704K
 TOSHIBA 22BL712G
 TOSHIBA 22D1333G
 TOSHIBA 22D1334G
 TOSHIBA 22L1333G
 TOSHIBA 22L1334
 TOSHIBA 24D1333G
 TOSHIBA 24D1334G
 TOSHIBA 24D1434
 TOSHIBA 24W1333
 TOSHIBA 24W1334
 TOSHIBA 24W1343
 TOSHIBA 24W1433
 TOSHIBA 24W1434
 TOSHIBA 24W1443DG
 TOSHIBA 32DV502B
 TOSHIBA 32DV504B
 TOSHIBA 32L1333
 TOSHIBA 32L1343
 TOSHIBA 32W1333
 TOSHIBA 32W1334
 TOSHIBA 32W1343
 TOSHIBA 32W1433
 TOSHIBA 32W1434DG
 TOSHIBA 32W1534DG
 TOSHIBA 37BV700G
 TOSHIBA 37BV701G
 TOSHIBA 40BV700G
 TOSHIBA 40L1333
 TOSHIBA 40L1334
 TOSHIBA 40L1343
 TOSHIBA 40L1533DG(V2)
 TOSHIBA 40L1534DG
 TOSHIBA 43UA2063DA
 TOSHIBA 43UA3A63DB
 TOSHIBA 43UA3A63DG
 TOSHIBA 46BL712G
 TOSHIBA 48L1433
 TOSHIBA 48L1435
 TOSHIBA 48L1443
 TOSHIBA 48L1453
 TOSHIBA 49UA2063DA

TOSHIBA 49UA3A63DB
 TOSHIBA 49UA3A63DG
 TOSHIBA 50UA2063DA
 TOSHIBA 55UA2063DA
 TOSHIBA 55UA3A63DB
 TOSHIBA 55UA3A63DG
 TOSHIBA 58UA2063DA
 TOSHIBA 58UA3A63DB
 TOSHIBA 58UA3A63DG
 TOSHIBA 65UA2063DA
 TREV I LTV1901HD
 TREV I LTV1902SAT
 TREV I LTV1903SAT
 TREV I LTV2001SAT
 TREV I LTV2019SA
 TREV I LTV2022HD
 TREV I LTV2024HD
 TREV I LTV2201HD
 TREV I LTV2202SAT
 TREV I LTV2204SAT
 TREV I LTV2401SAT
 TREV I LTV2402SAT
 TREV I LTV2801HD
 TREV I LTV3201HD
 TREV I LTV3206SAT
 TREV I LTV4001HD
 TREV I LTV4004SAT
 TREV I LTV5001HD
 TUCSON TL19822T
 TUCSON TL2204B15
 TUCSON TL2204B185
 TUCSON TL2204B274
 TUCSON TL2204V12TC
 TUCSON TL220W274
 TUCSON TL2404B13
 TUCSON TL2404B180
 TUCSON TL2404B272
 TUCSON TL2604B11
 TUCSON TL2804B274
 TUCSON TL3204B11
 TUCSON TL3204LED13
 TUCSON TL32LED300B15
 TUCSON TL32LED300B16
 TUCSON TL39DLED309B
 TUCSON TL40UHD19NS
 TUCSON TL4804DLED14
 TUCSON TL485DLED309B16
 TUCSON TL4904DLED15
 TUCSON TL55DLED305B16
 TURBO-X TXV2254
 TURBO-X TXV2454
 TURBO-X TXV2850D
 TURBO-X TXV2854
 TURBO-X TXV3234
 TURBO-X TXV3250D
 TURBO-X TXV3250FH
 TURBO-X TXV3250FSMT
 TURBO-X TXV3254
 TURBO-X TXV3954
 TURBO-X TXV4054
 TURBO-X TXV4350D
 TURBO-X TXV4354
 TURBO-X TXV4370SMT
 TURBO-X TXV5050D
 TURBO-X TXV5050SMT
 TURBO-X TXV5070SMT
 TURBO-X TXVU4370SMT
 TURBO-X TXVU5050SMT
 TURBO-X TXVU5570FSMT
 TURBO-X TXVU5570SMT
 TVSTAR LED22F2
 TVSTAR LED24F1
 TVSTAR LED24F4
 TVSTAR LED32RV5
 TVSTAR LED42F1
 ULTRAVOX "TVC20" "TXTUX206"
 ULTRAVOX UX19LC10
 ULTRAVOX "UX20620" "TXT"
 ULTRAVOX UX22LC10
 UNITED FTV15L60IT
 UNITED LTV15L60
 UNITED LTV15L60IT
 UNITED LTV27W51
 UNITED LTV30W51
 UNITED LTV30W51HD
 UNITED LTV32W51
 UNITED LTV32W53ITLCD
 UNITED TVD9022
 UNITED UTV21X56
 VESTEL 17MB01TFF
 VESTEL 17MB01TFT
 VESTEL 28630IDTV
 VESTEL CARIBIC

VESTEL CARIBICLCD
 VESTEL CORTINAS
 VESTEL CT7281
 VESTEL CT73681
 VESTEL DUBLINIIS
 VESTEL DUBLINS
 VESTEL GLASGOWM
 VESTEL GLASGOWS
 VESTEL MERANOSII
 VESTEL MERANOSIII
 VESTEL PALERMOIIS
 VESTEL PALERMOS
 VESTEL SANMARINOS
 VESTEL SIENAS
 VESTEL TORNADO
 VIDEOTON WPL107S
 VORTEX LEDV32E9D
 VORTEX VLED24E12D
 VORTEX VLED24E16D
 VORTEX VLED24E1D
 VORTEX VLED32ED2D
 WALKER WP20LCD
 WDEZI DZ32-190058
 WELLINGTON W32HD860BU
 WESTWOOD WA19LED
 WESTWOOD WA20LED
 WHITEWESTINGHOUSE
 MCC22LEDFHD
 XD 40F2ESAT
 XD XD22F1V
 XD XD22F2VSAT
 XD XD22FHV
 XD XD22SF2V
 XD XD24F1V
 XD XD24H1V
 XD XD24H2V
 XD XD24SH3VSAT
 XD XD28H1V
 XD XD28H2VSAT
 XD XD28HDV
 XD XD32H1V
 XD XD32H2EWSAT
 XD XD32H2V
 XD XD32H2VSAT
 XD XD32H3VSAT
 XD XD32SH2VSAT
 XD XD39F2VSAT
 XD XD40F1V
 XD XD40F2V
 XD XD43SF2V
 XD XD43SF3VSAT
 XD XD43SF4VSAT
 XD XD49SF1V
 XD XD50S24KVSAT
 XD XD50S34KVSAT
 XD XD50S4KVSAT
 XD XD50SF2V
 XD XD55S4K2VSAT
 XD XD55S4KVSAT
 XD XD55SF2V
 XIRON 37110
 XIRON 37130
 ZAPP ZAPP213
 ZAPP ZAPP217
 ZAPP ZAPP233
 ZAPP ZAPP259
 ZAPP ZAPP261
 ZAPP ZAPP735
 ZEM ZM2103
 ZEPHIR T24FHD