




# 6. DASHBOARD CONTROL

**1. Start**


**A**  **4s**

**B**  **Green LED: Remote Control Off**

**2B. 20 °C**


 **1s** **20 °C**

**2C. Favourite**

 **1s**


**\* Default: Mixed&Coloured 59' 20 °C**

**2A. ECO 40-60**

 **1s**


**ECO 40-60**


**3. Pause \***

 **1s**


**\* After 20 Seconds From Start: ||**


**4. Turn Off**

**A**  **3s**

**B**  **\*After 60 s**

**5. Door Opening**

**A**  **End Cycle - Pause or Off Status**

**B**  **After 60s**

**INFO**

 [go.he.services/c-nova](http://go.he.services/c-nova) 

Available Languages

DE	ES	FR	EN
SR	CS	PL	RO
PT	DA	SV	FI
IT	SL	HR	NL
HU	BG	SK	UKR
EL	NO	TR	...

Google Play and the Google Play logo are trademarks of Google LLC. Apple and Apple Logo are trademarks of Apple Inc., registered in the U.S. and other countries.


# CANDY



41052014









To download any other further information in your language, please go to:  
[go.he.services/c-nova](http://go.he.services/c-nova)








Download the hOn App



# NOVA

-  **INSTALLATION**
-  **APP SETUP**
-  **REMOTE CONTROL**
-  **PROGRAMMES**
-  **MAINTENANCE**
-  **DASHBOARD CONTROL**









# 1. INSTALLATION









\*

- EN A: Prewash B: Softeners C: Washing
- IT A: Prelavaggio B: Ammorbidente C: Lavaggio
- DE A: Vorwäsche B: Weichspüler C: Waschen
- ES A: Prelavado B: Suavizante C: Lavado
- FR A: Prelavage B: Adoucissant C: Washing
- BG A: Предпране B: Омекшители C: Пране
- TR A: Ön yıkama B: Yumuşatıcılar C: Yıkama
- HR A: Pretpranje B: Omekšivači C: Pranje
- HU A: Előmosás B: Óblító C: Mosás
- SL A: Predpranje B: Mehčalec C: Pranje
- SR A: Predpranje B: Omekšivač C: Pranje
- CS A: Předpírka B: Změkčovačka C: Praní
- PL A: Pranie Wstępne B: Środek Zmiękczający C: Pranie
- RO A: Prespălare B: Balsam De Rufe C: Spălare
- SK A: Predpírka B: Zmäkčovače C: Pranie
- UKR A: Попереднє Прання B: Пом'якшувач C: Прання
- EL A: Προ-Πλύση B: Μαλακτικά C: Κυριως Πλύση
- NL A: Voorwas B: Wasverzachter C: Hoofdwass
- PT A: Pré Lavagem B: Aditivos C: Lavagem
- DA A: Forvask B: Blødgøringsmidler C: Vask
- SV A: Förtvätt B: Sköljmedel C: Tvätt
- FI A: Esipesu B: Huuhteluaine C: Pesu
- NO A: Forvask B: Skylløs C: Vask

# 2. APP SETUP



# 3. REMOTE CONTROL



# 4. PROGRAMMES



		°C	kg
1	ECO 40-60	-	kg max.
2	20°C	20°	kg max.
3	* ☆	**	**

\*DEFAULT = Mixed&Coloured 59° 20 °C  
 \*\*FAVOURITE: CUSTOMIZABLE FROM APP  
 ALL OF THE OTHER CYCLES AVAILABLE FROM THE APP

# 5. MAINTENANCE

